

**VEEMUX® Series**

**SM-nXm-HD4K**


**HDMI 4K Video Matrix Switch  
 Installation and Operation Manual**



Front and Rear View of SM-16X16-HD4K



Front and Rear View of SM-32X32-HD4K



Rear View of SM-16X16-HD4K with cable tray installed



Rear View of SM-32X32-HD4K with cable tray installed

## TRADEMARK

VEEMUX and the NTI logo are registered trademarks of Network Technologies Inc in the U.S. and other countries. All other brand names and trademarks or registered trademarks are the property of their respective owners.

## COPYRIGHT

Copyright © 2010-2024 by Network Technologies Inc. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written consent of Network Technologies Inc, 1275 Danner Drive, Aurora, Ohio 44202.

## CHANGES

The material in this guide is for information only and is subject to change without notice. Network Technologies Inc reserves the right to make changes in the product design without reservation and without notification to its users.

## FIRMWARE VERSION

Current Firmware version for SM-16X16-HD4K; v2.0  
Current Firmware version for SM-32X32-HD4K; v1.01

# TABLE OF CONTENTS

<b>Introduction</b> .....	<b>1</b>
Supported Web Browsers.....	1
<b>Materials</b> .....	<b>2</b>
<b>Features and Functions</b> .....	<b>3</b>
<b>Installation</b> .....	<b>4</b>
To Mount to a Rack.....	4
Make All Connections.....	5
<b>Operating the VEEMUX</b> .....	<b>8</b>
Front Panel LCD with Keypad Control.....	8
LCD Menus.....	9
Save and Load (Recall) Config.....	10
<b>RS232 Control</b> .....	<b>11</b>
Baud Rate.....	11
Command Protocol.....	12
Autostatus.....	13
NTI Switch Control Program For Windows 7, 8,10 and 11.....	13
SerTest- RS232 Interface Test Program.....	14
Main Options.....	14
Matrix Operations.....	14
Ethernet Operations.....	14
Setup Options.....	15
<b>Ethernet Control</b> .....	<b>16</b>
Telnet Interface-Port 2000.....	16
Telnet Interface-Port 2005.....	18
Command Summary.....	18
Command Detail.....	19
RU-Read Unit Size.....	19
RO-Read Connection for Output Port.....	19
CS- Connect Output Port to Input Port.....	19
CA- Connect All Output Ports to Input Port.....	19
SS_01- Enable Auto Status Mode.....	20
SS_00- Disable Auto Status Mode.....	20
SX- Examine connections.....	20
Terminate telnet session.....	21
Web Interface.....	22
Enter the Password.....	22
Main Menu.....	23
Video Switch Page.....	24
Administration.....	25
System Configuration.....	25
Network Configuration.....	26
X509 Certificate.....	27
Video Input Names.....	29
Video Output Names.....	30
Scanning Sequences.....	31
User Config.....	33
EDID Options.....	34
Hot Plug Options.....	36
EDID Mix.....	37
Update Firmware.....	38
Standby Mode.....	39
Logout.....	39
Support.....	40
Reboot.....	40
<b>Device Discovery Tool</b> .....	<b>41</b>
<b>Infrared Remote Control</b> .....	<b>42</b>
Materials.....	42
Buttons.....	43

Operation .....	44
Changing Ports .....	44
Channel Surfing .....	44
Jump To Input.....	45
Jump To Output.....	45
Connect All .....	45
Save and Recall.....	46
Multiple Switch Control .....	46
Canceling a Command .....	46
Technical Specifications For IRT-UNV .....	47
Troubleshooting the IRT-UNV .....	47
Troubleshooting the VEEMUX.....	47
<b>Creation of Custom x509 Certificates .....</b>	<b>48</b>
<b>General Technical Specifications .....</b>	<b>58</b>
<b>Index .....</b>	<b>59</b>
<b>Warranty Information.....</b>	<b>59</b>

## TABLE OF FIGURES

Figure 1- Secure switch to a rack .....	4
Figure 2- Connect video sources to VEEMUX .....	5
Figure 3- Connect display devices to VEEMUX.....	5
Figure 4- Connect RS232 control terminal to VEEMUX.....	6
Figure 5- Connect VEEMUX to local area network .....	6
Figure 6- Attach AC power cord to VEEMUX.....	7
Figure 7- Web interface Login page.....	22
Figure 8- Administrator Menu .....	23
Figure 9- Main menu and Video Switch page .....	23
Figure 10- System Configuration page .....	25
Figure 11- Network Configuration page .....	26
Figure 12- Network Configuration Page (continued).....	27
Figure 13- Video Input Names page .....	29
Figure 14- Video Output Names page .....	30
Figure 15- Scanning Sequence page .....	31
Figure 16- Users page .....	33
Figure 17- User configuration page .....	33
Figure 18- EDID Options page.....	34
Figure 19- Store EDID to Input Port options .....	35
Figure 20- EDID Mix page .....	37
Figure 21- Update Firmware page .....	38
Figure 22- VEEMUX in Standby Mode.....	39
Figure 23- Logout of the VEEMUX web interface .....	39
Figure 24- Support Tab.....	40
Figure 25- System Reboot .....	40
Figure 26- Device Discovery Tool page.....	41

## INTRODUCTION

The VEEMUX HDMI 4K Video Matrix switch (VEEMUX) provides non-blocking access to up to 32 4k x 2k video sources from up to 32 displays. Locate computers up to 20 feet away from 4K @ 60Hz displays or 50 feet from 1080p @ 60Hz displays, enabling easy access to multiple servers in various locations. Cables longer than 50 feet can be used for 1080p displays provided they have the built-in digital video equalizer (also known as an "active HDMI cable").

### Models Available:

**SM-16X16-HD4K** for access to up to 16 4k x 2k video sources from 16 displays.

**SM-32X32-HD4K** for access to up to 32 4k x 2k video sources from 32 displays.

**Application Note:** Greater distances can be achieved using an ST-C64K-300 Video Extender supporting up to 4K@30hz. The ST-C64K-300 does not support HDMI2.0 and HDCP2.2. Be sure the video source connected is providing a 4K@30Hz signal for the ST-C64K-300 extender to work.

### Features:

- Configure and control the switch through serial port, front panel buttons, web interface, or optional infrared control.
- Supports HDMI interface for crisp and clear video quality on flat panel displays.
- Supports HDMI operation up to 18 Gb/second
- Resolutions to 3840x2160 (UHD), and 4096x2160 (4K) @ 60Hz / RGB/YCBCR 4:4:4.
  - Supports up to 12 bits deep color.
  - Supports 4:4:4, 4:2:2 and 4:2:0 pixel encoding.
- EDID learning for the support of any HDMI display device.
- Built in default EDID configuration tables for 1080p and 4K resolution.
- Each output provides one video signal.
- Each input can be independently connected to any or all outputs.
  - Multiplatform support: Windows 7/8/10/11, Windows Server 2008/2012/2016/2019/2022, Linux, FreeBSD, and MAC OS 10/11/12/13.
- Up to 16 users (including "root") can be configured to control the VEEMUX from the Web Interface
- HDMI 1.4 and 2.0 compatible.
- HDCP 1.4 and 2.2 support.
- Passes embedded audio.

## Supported Web Browsers

Most modern web browsers should be supported. The following browsers have been tested:

- Microsoft Internet Explorer 6.0 or higher
- Microsoft Edge 86 or higher
- Netscape 7.0 or higher
- Mozilla FireFox 40 or higher
- Google Chrome 9.0.5 or higher
- Apple Safari 5.0.3 or higher
- Opera 11.0 or higher

Set your browser to always check if there is a newer version of the page than the version stored in cache. This action will ensure that it will display the most up-to-date information.

## MATERIALS

### Materials supplied with this kit:

- NTI SM-16X16-HD4K (or SM-32X32-HD4K) HDMI 4K Video Matrix Switch
- Power Cord- country specific
- CT6182 DB9 Female-to-RJ45 Female adapter
- CB7339- 5 foot CAT5e patch cable
- 4pcs #10-32 x 3/4" pan head screws and #10-32 cage nuts (server cabinet mounting hardware)
- 34 pcs zip ties (16X16) or 66 pcs zip ties (32x32)
- URL Slip with path to this manual

### Materials *Not* supplied but **REQUIRED**:


- HD-xx-MM cable for each 4K monitor being connected to the switch and for each PC being connected- available in 3, 6,10, 15,25,30 and 50 foot lengths
  - 3/6/10/15 and 25 foot cables support resolutions to 4Kx2K.
  - 30 and 50 foot cables support resolutions to 1080p.
- HD-ACT-xx-MM 4K HDMI Active Cable with Built-In Signal Booster- available in 20,25,30,40,50,60,75 and 100 foot lengths
  - 20/25/30/40/50 and 60 foot cables support Ultra-HD 4Kx2K resolutions up to 4096x2160 @60Hz
  - 75 and 100 foot cables support Ultra-HD 4Kx2K resolutions up to 4096x2160 @30Hz

where:

xx is the length of the cable in feet

MM indicates male-to-male connector

**FEATURES AND FUNCTIONS**



Item	Type	Description
1	<b>IR LED</b>	For indicating when an infrared signal is being received from the IR remote control
2	<b>IR Receiver</b>	this receives the IR signal from the infrared remote control (IRT-UNV sold separately)
3	<b>Power/Standby LED</b>	Indicates when the VEEMUX is either ready for user interface (green) or in standby mode (red)
4	<b>System Reset button</b>	press this button to cycle the VEEMUX processor and reboot the system
5	<b>LCD Display</b>	indicates what inputs (video sources) are connected to the labeled output (display device)
6	<b>Menu buttons</b>	Used to control LCD menu navigation
7	<b>Out and In buttons</b>	Used to select which outputs (display devices) to connect to which inputs (video sources) when pressed
8	<b>Power Switch</b>	To control the ON/OFF function of the switch
9	<b>IEC Connector</b>	For attachment of country-specific power cord
10	<b>HDMI Female</b>	For connecting to HDMI video sources
11	<b>HDMI Female</b>	For connection of HDMI display devices
12	<b>RJ45 Female</b>	RS232 (DCE) connection for attachment of RS232 control cable
13	<b>RJ45 Female</b>	For connection of CATx cable to Local Area Network (LAN) for WEB interface

## INSTALLATION

This NTI switch was designed to be mounted to a rack. It includes rack mount flanges to make attachment to a rack easy and a cable tray to easily secure attached cables to prevent disconnection.

### To Mount to a Rack

1. Install 4 cage nuts (supplied) to the rack in locations that line up with the holes in the mounting flanges on the NTI switch.
2. Secure the NTI switch to the rack using four #10-32X3/4" screws (supplied). Each screw should be of sufficient length to go completely through the NTI mounting flange, rack frame and fully engage all threads in the cage nut. Be sure to tighten all mounting screws securely.
3. Attach all cables securely to the switch and where necessary supply adequate means of strain relief for cables.




Figure 1- Secure switch to a rack



## Make All Connections

1. Connect a HDMI male cable between each video source and an "HDMI INx" connector on the rear of the VEEMUX.




Figure 2- Connect video sources to VEEMUX

2. Connect a HDMI male cable between each display device and an "HDMI OUTx" connector on the rear of the VEEMUX.




Figure 3- Connect display devices to VEEMUX

3. If the VEEMUX will be controlled using RS232, then make a connection between the “RS232” port on the VEEMUX and a serial port on a PC. A DB9M-to-RJ45F adapter and 5 foot CAT5 patch cable have been provided to help with this connection if needed.




Figure 4- Connect RS232 control terminal to VEEMUX

4. To make a remote connection, over the Ethernet, from anywhere on the local area network, connect a CAT5/5e/6 Ethernet cable with RJ45 male connectors on the ends, wired straight through (pin 1 to pin 1, pin 2 to pin 2, etc.).




Figure 5- Connect VEEMUX to local area network

5. Connect the powercord to the VEEMUX and plug it in.




Figure 6- Attach AC power cord to VEEMUX

6. Power ON all components. (In any order, which ones are first and which are last does not matter.)

## OPERATING THE VEEMUX


The VEEMUX video matrix switch has four methods of control:

- Front Panel LCD with Keypad
- Directly via an RS232 Interface
- Remotely via Ethernet
- Infrared Remote

Every unit comes standard with all control methods built-in. An IRT-UNV-IR Remote Control is required to use the Infrared option. No software is involved (see Infrared Control on page 42). With the RS232 option, there are no external devices to be purchased. NTI provides software commands as well as a test program to ensure the RS232 functions properly (see page 11 – RS232 Control).


### Front Panel LCD with Keypad Control

The front panel LCD and keypad allow the user to monitor switch status and route any user to any video source on the switch. When the unit is first powered-up, each monitor is automatically connected to the video source of its equal number (i.e. monitor 1 to source 1, monitor 2 to source 2, monitor 3 to source 3, etc.). (After configurations have been saved (page 24), upon power-up the VEEMUX will load the configuration saved into memory location 0.) Along with the routing of the inputs (video sources) to the outputs (monitors) the keypad and LCD allow the users to configure the RS232 control interface. The keypad buttons perform the following functions:



#### Key Functions:

- Up Arrow**- Scroll up the menu
- Down Arrow**- Scroll down the menu
- Left Arrow (Enter Key)**- Select the menu item
- List** - Open the menu, or exit the menu (also used to back out of the menu, one step at a time)
- Out-1- through 16** Used in command sequence to select which output (display device) to connect
- In-1-though 16** Used in command sequence to select which input (video source) to connect



**To quickly change a connection**, simply press the associated port number and then the “In” or “Out” button to designate the video source or the display (respectively). Alternatively, the “In” or “Out” button can be pressed, then the port number, followed by the “Enter” button.

Multiple displays can be connected to a single video source using one command sequence:

`<In> xx<Out>xx<Out>xx<Out>xx<Out>xx<Enter>` or  
`<Out>xx<Out>xx<Out>xx<Out>xx <In> xx <Enter>` (where xx is the port number)

To configure the VEEMUX, use the Menu keys.

Press the **List** button to list your main menu options:

- 1- Serial
- 2- Ethernet
- 3- DDC
- 4- Standby
- 5- Save Config
- 6- Load Config

Use the **Up** and **Down Arrow** keys to scroll through this list.

Use the **Enter** Key to select a menu item.

Press the **List** button again to exit the menu.

If, while in a menu, you pause for more than 5 seconds, you will automatically exit the menu.

## LCD Menus

### Serial Menu

Under the “Serial” menu are two parameters:

- 1- Baud rate
- 2- Address

These parameters are used when the VEEMUX is controlled through an RS232 connection (page 11). If you select Baud rate, use the arrow keys to toggle through the available baud rates. The baud rate can be set to 115200, 57600, 38400, 19200, 9600, 4800, 2400, or 1200.

If you select Address, use the arrow keys to toggle through the address options (01-15). This is also the switch address used in conjunction with the IR Remote operation (page 46).

### Ethernet Menu

Under “Ethernet” menu are several parameters:

- 1- Mode
- 2- IP Address
- 3- Mask
- 4- Gateway
- 5- Pref. DNS
- 6- Alt. DNS

The Mode parameter will let you select between a manual IP setting, a DHCP assigned dynamic IP address setting, or disabling the Ethernet port. An asterisk indicates which mode is configured, an arrow shows which mode is being selected. To change the configured setting and move the asterisk, select the desired mode and press the **Enter** button.

If you choose a manual IP setting, the IP parameter provides the fields for entering a valid IP address. Use the up and down arrows to advance the numbers, and the **Enter** button to move from field to field. Press **List** to exit this screen.

Selections 3, 4 are necessary to apply valid values for your Subnet Mask and Gateway. Navigate these settings as described for setting the IP address.

Selections 5 and 6 are not used at this time and are therefore unnecessary.

## DDC Menu

DDC enables the video source to get EDID information from the display device. This enables the video source to automatically select the optimal resolution for the display by receiving, at power up, information from the display device concerning its resolution specifications.

Under the “DDC” menu are five parameters:

- 1- **Chose Input** (Choose Input)
- 2- **All Inputs**
- 3- **FacDefault1**
- 4- **UsrDefault1**
- 5- **ReloadOptn**

- 1) **Choose Input**- select the EDID information source for each input individually, or
- 2) **All Inputs**- select EDID information source for all inputs at once.

Within these sections you will need to select between:

**default 1**- the inputs will get EDID information from a predefined table in the VEEMUX supporting 1080p resolution

**default 2**- the inputs will get EDID information from a predefined table in the VEEMUX supporting UHD resolutions

**From Out (?)**- select which Output port the Input will get EDID information from regardless of which output it is connected to

**DDC Mix(?)**- select which Input will receive EDID information that is common to the Outputs selected on the “DDC Mix” page (page 37) for that input

- 3) **FacDefault1**- Select this to use the factory default EDID data for DDC “Default 1” configuration
- 4) **UsrDefault1**- Select this to replace the EDID information stored in the VEEMUX for “Default 1” with the EDID data from the monitor presently connected to Output 1.
- 5) **ReloadOptn**- Select this and choose to **enable** or **disable** this feature. When enabled, the switch will refresh DDC data stored in the VEEMUX each time the VEEMUX is power-cycled. The DDC data will be based on the current DDC configuration settings.

## Standby

The fourth option in the main menu is “Standby”. When Standby is selected, the VEEMUX switch will immediately go into a power saver mode and the LCD display will go blank. It will remain in this state until

- 1) any button is pressed on the front panel,
- 2) the Standby button is pressed on the optional IR Remote Control (page 43), or
- 3) the “Disable Standby” button is pressed in the web interface (page 39)

## Save and Load (Recall) Config

The SM-mXn6-HD4K includes the ability to save and recall up to 100 switch configurations using the LCD menu. The switch configurations define the current port connections, volume control settings, and video blank status.

**Note: The IRT-UNV IR Remote (page 42) can also be used to access these configurations by using the “SAVE” and “RECALL” buttons.**

To save a configuration, select “Save Config” from the main menu followed by a numeric button(s) (0-99) corresponding to the memory slot the configuration is to be saved in. Press **Enter** after your selection to force the current configuration to immediately be saved to the selected memory slot.

Configurations can be loaded (recalled) in much the same manner. To recall, select “Load Config” from the main menu followed by the numeric button(s) (0-99) corresponding to the memory slot from which the configuration is to be recalled. Press **Enter** after your selection to immediately force the switch to change the current switch configuration to match that of the configuration recalled.

## RS232 CONTROL

RS232 enables the VEEMUX to be remotely controlled via RS232. To control the VEEMUX via RS232 the user has four options:

- write a program that runs on a PC using the Command Protocol (page 12)
- use the Matrix Switcher's Control Program (page 13)
- use the SerTest program (page 14)
- Remote Connection

The RS232 Interface is designed to meet the RS232C standard and can be controlled from any CPU or other controller with an RS232 communications port. The pin-out for the RJ45 connector on the unit is as follows:

### RS232 (RJ45) CONNECTOR

PIN	SIGNAL	FUNCTION
1	-	No connection
2	-	No connection
3	RX+	Receive data (TXD at host)
4	GND	Ground
5	-	No connection
6	TX+	Transmit data (RXD at host)
7	-	No connection
8	-	No connection

A 5 foot patch cable and adapter, RJ45-to-DB9, have been provided for connection to most CPUs (see page 6).

### Baud Rate

The baud rate can be changed by selecting MENU on the front panel keypad, using the OSD menu, using Telnet commands (page 16) or from the RS232 commands (page 12). The baud rate can be set to 115200, 57600, 38400, 19200, 9600, 4800, 2400, or 1200. A data protocol of 8 data bits, no parity, and 1 stop bit is used for communications. The default baud rate setting is 9600.

## Command Protocol

CPU controller commands supported by the unit are defined below. All commands must be terminated with a <CR> (carriage return). When a command is sent, the entire string is echoed back along with a response from the addressed unit as shown in the Command Definitions table (below). All characters in the command string are case sensitive (see Command Definitions table), and all numbers below 10 must have a leading 0 (ex: 1 = 01).

### Legend:

(All numbers must be two digits)

SW	:	Switch (01-15)	MM	:	Save Into Memory Bank (00-99)
BR	:	Baud Rate Code	LL	:	Load From Memory Bank (00-99)
OP	:	Output Port (01-MAXOUTPUTS)	<CR>	:	Carriage Return (Hex 0xD)
IP	:	Input Port (01-MAXINPUTS)	ip	:	IP address

### Command Definitions

Command String	Good Response	Description
CS SW,IP,OP	*<CR>	VIDEO Connect One Output/User Port To Input/CPU Port
CA SW,IP	*<CR>	VIDEO Connect All Output/User Ports To Input/CPU Port
RO SW,OP	*<CR>IP<CR>	VIDEO Read Connection For Output/User Port
VB SW,OP,01	*<CR>	Blank the video for specific Output/User Port
VB SW,OP,00	*<CR>	Unblank the video for specific Output/User Port
CC SW,MM	*<CR>MM<CR>	Save Matrix Connections Into Memory Bank xx Xx=00-99
RC SW,LL	*<CR>LL<CR>	Restore Matrix Connections From Memory Bank
CB 00,BR	None	Change baud rate of serial line, BR=11(5200),57(600),38(400),19(200)96(00),48(00),24(00),12(00) Factory default is 9600
RS SW	*<CR>	Reboot Unit
RV SW,00	*<CR>string0<CR>	Read NTI Version String
RU SW	*<CR>IP,OP<CR>	Read Unit Size
EA SW,ip	*<CR>	Set the IP address, ip is in xxx.xxx.xxx.xxx format, number of digits is minimum 1 and maximum 3 for each field Leading zeroes are accepted
EM SW,ip	*<CR>	Set the Subnet mask, ip is in xxx.xxx.xxx.xxx format, number of digits is minimum 1 and maximum 3 for each field. Leading zeroes are accepted
EG SW,ip	*<CR>	Set the default gateway, ip is in xxx.xxx.xxx.xxx format, number of digits is minimum 1 and maximum 3 for each field Leading zeroes are accepted
ET SW,timeout	*<CR>	Set the website timeout; timeout = numeric string of timeout in seconds. Values: 60, 300, 600, 900, 1800, 3600, 7200, 18000, 28800
RA SW*	<CR>ip<CR>	Read the IP address, ip is in xxx.xxx.xxx.xxx format, number of digits is minimum 1 and maximum 3 for each field Leading zeroes are accepted
RM SW*	<CR>ip<CR>	Read the Subnet mask, ip is in xxx.xxx.xxx.xxx format, number of digits is minimum 1 and maximum 3 for each field Leading zeroes are accepted
RG SW*	<CR>ip<CR>	Read the default gateway, ip is in xxx.xxx.xxx.xxx format, number of digits is minimum 1 and maximum 3 for each field Leading zeroes are accepted
RT SW*	<CR>timeout<CR>	Read the website timeout; timeout = numeric string of timeout in seconds. Values: 60, 300, 600, 900, 1800, 3600, 7200, 18000, 28800
SS SW,00	*<CR>	Disable Autostatus feature (see below)
SS SW,01	*<CR>	Enable Autostatus feature (see below)
GO SW,OP	*<CR>go SW,OP:IP<CR>	Read connection of a Video Output Port to Video Input Port
GM SW,00	*<CR>go SW,OP:IP (all ports)<CR>	Read connection matrix of all Video Output ports

If the first field is not a known command (as listed above) or SW field is different from the serial address programmed in the switch memory, the command will be ignored. If the SW field corresponds to the unit address, but the syntax is wrong after this field, the switch will answer with a bad response ?<CR>.



## Autostatus

When Autostatus is enabled, any output-to-input connection change in the VEEMUX will cause an Autostatus message to be sent via RS232 to the administrator. The format of the message would be "pc SW,OP:IP<CR>"

Example of an Autostatus message:

```
pc 01,01:04<CR>
```

which means "At the switch with unit address 01, the output (01) has changed connection to input 04."

**Notes:** *Message to the administrator will be delayed by any RS232 traffic being received by the switch from the administrator.  
Autostatus must be disabled before using SerTest or the Matrix Switcher's Control Program (page 13).*

By default, Autostatus is disabled and must be manually enabled. Autostatus is also disabled any time the power to the VEEMUX is interrupted.

## NTI Switch Control Program For Windows 7, 8,10 and 11

The NTI Switch Control Program is an easy and powerful graphical program that controls NTI matrix switches through an RS232 interface. The NTI Switch Control Program is downloaded from <http://www.networktechinc.com/download/d-vmtx-dvi.html>.

To install the Program after downloading

1. Locate the **Setup.exe** in the directory the program was downloaded to and double-click on it
2. Follow the instructions on the screen

The NTI Switch Control Program performs best on monitors set to a screen resolution of at least 800 X 600. Instruction for using the NTI Switch Control Program is available by opening "MSCP Help" in the "NTI" program group once the program has been installed and is open on the screen.

To open "MSCP Help" from the Windows desktop

1. Click on **START**
2. Click on **PROGRAMS**
3. Click on **NTI**
4. Click on **MSCP Help**

**Note:** *While in Scan Mode, the video radio buttons shown on the Switch page of the NTI Switch Control Program may not be in sync with the connection changes within the VEEMUX. Connections will change without updating the image on the screen.*

## SerTest- RS232 Interface Test Program

This software allows a user to test the functions of an NTI server switch, matrix switch or Multi-user/Multi-platform switch RS232 interface. The SerTest program is automatically loaded when installing the NTI Switch Control Program as described above. The SerTest program, located in the NTI program group, generates a main menu with the 4 selections described below:

### Main Options

- Matrix Operations - send commands to the matrix unit.
- Ethernet Operations - set Ethernet connection variables
- Setup Options - set COM port, baud rate, and unit address
- About SerTest - display the program version

### Matrix Operations

Key	Selection	Description
1)	Connect Video Output/User to an Input/CPU	- connect an output to an input
2)	Connect All Video Outputs/Users to an Input/CPU	- connect all outputs to an input
3)	Connect Audio Output/User to an Input/CPU	- connect an output to an input (audio ports only)
4)	Connect All Audio Outputs/Users to an Input	- connect all outputs to an input (audio ports only)
5)	Change Mute Status for Audio Output/User	- mute or un-mute the Audio port output
6)	Change Volume for Audio Output/User	- change Audio port output volume
7)	Read Connection for Video Output/User	-read the connection of a specific video output
8)	Read Connection for Audio Output/User	-read the connection of a specific audio output
9)	Read Mute and Volume for Audio Output/User	- read the volume and the mute status of the specified output (audio ports only)
a)	Save I/O Connections into Unit Memory	-save the connections into switch memory bank
b)	Restore I/O Connections from Unit Memory	-restore the connections from switch memory bank
c)	Change All Units Baud Rate (9600/COM1:)	-change RS-232 Baud rate of all switches -the current baud rate and serial port are displayed in parentheses
d)	Reset Unit	- send a reset (reboot) command to the switch - the current unit address is displayed in parentheses
e)	Reset All Units	- send an internal reset command to all switches
f)	Read Unit Size	- read the switch size (number of inputs and outputs)
g)	Read Unit Version/Revision String	-read a string containing the switch version, type, and size
h)	Save All Units I/O Connections into Units Memory	-save the connections into switch memory bank, command for all switches
i)	Restore All Units I/O Connections from Units Memory	-restore the connections from switch memory bank, command for all switches

Grayed keys are not applicable to this product

### Ethernet Operations

Key	Selection	Description
1)	Set Unit IP Address	- enter the desired IP address in xxx.xxx.xxx.xxx format - number of digits is minimum 1 and maximum 3 for each field. Leading zeroes are accepted
2)	Set Unit Subnet Mask	- enter the desired IP address in xxx.xxx.xxx.xxx format - number of digits is minimum 1 and maximum 3 for each field. Leading zeroes are accepted
3)	Set Unit Default Gateway	- enter the desired default gateway - number of digits is minimum 1 and maximum 3 for each field. Leading zeroes are accepted
4)	Set Unit Website Timeout	- set the website timeout; timeout = numeric string of timeout in seconds - Values: 60, 300, 600, 900, 1800, 3600, 7200, 18000, 28800 0 = no timeout
5)	Read Unit IP Address	- read the unit IP address in xxx.xxx.xxx.xxx format
6)	Read Unit Subnet Mask	- read the unit subnet mask in xxx.xxx.xxx.xxx format
7)	Read Unit Default Gateway	- read the unit default gateway in xxx.xxx.xxx.xxx format
8)	Read Unit Website Timeout	- read the current website timeout period in seconds - Values: 60, 300, 600, 900, 1800, 3600, 7200, 18000, 28800 0 = no timeout

**Setup Options**

Key	Selection	Description
1)	select Com port current: (COM1:)	- select PC serial port - the current PC serial port is displayed in parentheses
2)	select Baud rate current: (9600)	- select PC serial port baud rate - the current baud rate is displayed in parentheses
3)	set unit Address current: (1)	- select the unit address - the current address is displayed in parentheses
4)	set read timeout (5)	- select the time period (in seconds) the SerTest will wait for an answer to a command - the current time period is displayed in parentheses

For any selection that requires user input, the user is prompted. When commands are sent to the matrix unit, the command string and matrix unit responses are echoed to the screen. All commands generated by the program are formatted according to the information provided in sections above. If any transmission problems are detected, an error message is displayed.

Press <Esc> or <Enter> to back out to the main menu and press again to exit.

## ETHERNET CONTROL

### Telnet Interface-Port 2000

The Telnet Interface enables the user to control the switch using telnet client through an Ethernet connection. The telnet server (telnet must be enabled- see page 26) listens on ports 2000 and 2005. Port 2000 is for an operator telnet session while port 2005 is intended for a software control type session (see page 18 for more on Port 2005 control). For operator telnet control using the telnet interface and the current IP address, type the following in a command shell:

**telnet 192.168.1.30 2000**                    (for Port 2005 control, substitute “2005” for “2000” in this command)

The VEEMUX will prompt the user for a password. The user must enter the password followed by <Enter>.

The factory default password is "nti".

**Since Port 2005 control is initiated via software from a controller, rather than manually, the password requirement is not part of the command sequence.**

With a proper password sent the VEEMUX will respond with:

***Password Successful  
Connection Established***

The commands below are now available.

#### Telnet Interface- Port 2000 Commands

Command	Reply	Description
H(elp) or h(elp)	Displays the list of commands	Help
CS nn,mm	*<CR>	Connect One input nn To output mm
CA nn	*<CR>	Connect All Outputs To Input nn
RO mm	*<CR>nn<CR>	Read Connection For Output. Returns the number of the input nn connected to output mm
CC nn	*<CR>nn<CR>	Save Matrix Connections Into Memory Bank nn nn should be between 00 and 99
RC nn	*<CR>nn<CR>	Restore Matrix Connections From Memory Bank nn nn should be between 00 and 99
CB nn	*<CR>	Change baud rate of serial line, nn=12(00),24(00),48(00),96(00) Factory default is 9600.
RV 00	*<CR>string<CR>	Read NTI Version String
RU	*<CR>nn,mm<CR>	Read Unit Size Returns the number of inputs nn and the number of outputs mm
RS	*<CR>	Reboot Unit
Ss nn,dwt	*<CR>	Set value of Scan Mode dwell time (see page 9) for specific Output (nn) dwt = 000-255 (seconds) 000= disable Scan Mode

Command	Reply	Description
Gs nn	*<CR> dwt<CR>	Read set Scanning Sequence dwell time value (dwt) for specific Output (nn) in seconds (see also "Scanning Sequences" on page 31)
Sa nn,mm	*<CR>	Set scan list of individual output nn to all inputs mm
Sc nn	*<CR>	Clear scan list of individual output nn
S+ nn,mm	*<CR>	Add input mm to Scan List of output nn
S- nn,mm	*<CR>	Remove input mm from Scan List of output nn
Sx nn	*<CR>oooxxxxooooxxx<CR>	Display the Scan List of output nn (o=skip x=don't skip)
CP	User is prompted to introduce the password twice	Change password- five (5) characters minimum
<Ctrl>-<X> (see note 4 below)	Good Bye. Connection to host lost.	Quit telnet session
H(elp) or h(elp)	Displays the list of commands	Help

**Notes:**

1. The commands must be typed exactly as shown in the chart. The commands are case sensitive.
2. If a mistake is made, the user must backspace to the beginning and completely retype the command.
3. If a command is sent that the VEEMUX does not recognize or exceeds the configuration of the switch, the reply "?" may be received. Check the command syntax and try again.
4. To quit the telnet session, press the keyboard keys <Ctrl><X> + <Enter>.

## Telnet Interface-Port 2005

For a software control type of telnet interface session (versus operator telnet control through port 2000 as described on page 16), connect to the VEEMUX through the current IP address at port 2005. Use the command set below to control and acquire information from the VEEMUX.

**Note:** After establishing the connection, the unit will answer with a blinking prompt on the next line. If the connection fails it will answer with ?<CR>

**Note:** When using some controllers (Crestron for example), a slight delay may necessary to be added at the end of each command string.

**Legend:** (All numbers must be two digits)

OP : Output Port (01-MAXOUTPUTS)  
 IP : Input Port (01-MAXINPUTS)  
 <CR> : Carriage Return (Hex 0xD)

### Command Summary

Command String	Good Response	Description
RU<CR>	ru IP,OP<CR>	Read unit size
RO OP<CR>	pc OP,IP<CR>	Read connection for OP
CS IP,OP<CR>	*<CR>	Connect OP to IP
CA IP<CR>	*<CR>	Connect all outputs to IP
SS 01<CR>	*<CR>	Enable auto-status mode
SS 00<CR>	*<CR>	Disable auto-status mode
SX<CR>	See details	Examine connections
XX<CR>	*<CR>	Close connection

A <CR> (carriage return, 0x0D) is considered to be the end of the command string. If a string exceeds 16 characters, an end of string will be inserted automatically to avoid buffer overflow. An eventual <LF> (line feed, new line, 0x0A) after a <CR> will be ignored. A bad string will always be responded to with the ASCII character '?' followed by a <CR>.

**Note:** Always be sure to terminate your telnet session with the <X> - <X> - <Enter> command string.

## Command Detail

### RU-Read Unit Size

Command:

Byte 1	Byte2	Byte3
'R' (0x52)	'U' (0x55)	<CR> (0x0D)

Response:

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8	Byte 9
'r' (0x72)	'u' (0x75)	Space (0x20)	Input – 1st digit (0x30...0x32)	Input – 2nd digit (0x30...0x39)	',' (0x2C)	Output – 1st digit (0x30...0x32)	Output-2nd digit (0x30...0x39)	<CR> (0x0D)

This command will read the size of the unit. The response returns the number of inputs and the number of outputs in two-digit, ASCII code format. If the numbers are smaller than 10, the 1st digit is '0'.

### RO-Read Connection for Output Port

Command:

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
'R' (0x52)	'O' (0x4F)	Space (0x20)	Output – 1st digit (0x30...0x32)	Output – 2nd digit (0x30...0x39)	<CR> (0x0D)

Response:

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8	Byte 9
'p' (0x70)	'c' (0x63)	Space (0x20)	Output – 1st digit (0x30...0x32)	Output-2nd digit (0x30...0x39)	',' (0x2C)	Input – 1st digit (0x30...0x32)	Input – 2nd digit (0x30...0x39)	<CR> (0x0D)

This command will read the connection of an output port. The response returns the output port that is connected to the input port.

### CS- Connect Output Port to Input Port

Command:

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8	Byte 9
'C' (0x43)	'S' (0x53)	Space (0x20)	Input –1st digit (0x30...0x32)	Input –2nd digit (0x30...0x39)	',' (0x2C)	Output – 1st digit (0x30...0x32)	Output – 2nd digit (0x30...0x39)	<CR> (0x0D)

Response:

Byte 1	Byte 2
'*' (0x2A)	<CR> (0x0D)

This command connects the specified input port to the specified output port.

### CA- Connect All Output Ports to Input Port

Command:

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
'C' (0x43)	'A' (0x41)	Space (0x20)	Input – 1st digit (0x30...0x32)	Input - 2nd digit (0x30...0x39)	<CR> (0x0D)

Response:

Byte 1	Byte 2
'*' (0x2A)	<CR> (0x0D)

This command connects all output ports to the specified input port.

**SS\_01- Enable Auto Status Mode**

Command:

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
'S' (0x53)	'S' (0x53)	Space (0x20)	'0' (0x30)	'1' (0x31)	<CR> (0x0D)

Response:

Byte 1	Byte 2
'*' (0x2A)	<CR> (0x0D)

Auto status mode is disabled by default whenever the connection is established, and this command must be entered to enable it. When auto status mode is enabled, a message will be sent whenever an input/output connection changes from any source. The format of this message is given in the table below. The first two numeric digits are the output port number and the two after the colon are the number of the input port that is now connected to it.

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8	Byte 9
'p' (0x70)	'c' (0x63)	Space (0x20)	Output – 1st digit (0x30...0x32)	Output – 2nd digit (0x30...0x39)	':' (0x3A)	Input – 1st digit (0x30...0x32)	Input – 2nd digit (0x30...0x39)	<CR> (0x0D)

**SS\_00- Disable Auto Status Mode**

Command:

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
'S' (0x53)	'S' (0x53)	Space (0x20)	'0' (0x30)	'0' (0x30)	<CR> (0x0D)

Response:

Byte 1	Byte 2
'*' (0x2A)	<CR> (0x0D)

This command disables auto status mode.

**SX- Examine connections**

Command:

Byte 1	Byte 2	Byte 3
'S' (0x53)	'X' (0x58)	<CR> (0x0D)

Response:

Multiple lines, one line for each output:

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8	Byte 9
'p' (0x70)	'c' (0x63)	Space (0x20)	Output – 1st digit (0x30...0x32)	Output – 2nd digit (0x30...0x39)	':' (0x3A)	Input – 1st digit (0x30...0x32)	Input – 2nd digit (0x30...0x39)	<CR> (0x0D)

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8	Byte 9
'p' (0x70)	'c' (0x63)	Space (0x20)	Output – 1st digit (0x30...0x32)	Output – 2nd digit (0x30...0x39)	':' (0x3A)	Input – 1st digit (0x30...0x32)	Input – 2nd digit (0x30...0x39)	<CR> (0x0D)

Last line:

Byte 1	Byte 2
'*' (0x2A)	<CR> (0x0D)



**Terminate telnet session**

Command:

Byte 1	Byte 2	Byte 3
'X' (0x58)	'X' (0x58)	<CR> (0x0D)

Response:

Byte 1	Byte 2
'*' (0x2A)	<CR> (0x0D)

The unit will respond with '\*<CR>' and close the connection, terminating the telnet session. The unit is then available for future connections.

## Web Interface

A user may control the connections of the VEEMUX using a Web Interface via any web browser (see page 1 for supported web browsers). With the VEEMUX connected to a LAN through an Ethernet cable, a user can access the web interface controls inside the VEEMUX.

**FYI: To quickly locate a VEEMUX on the LAN and edit the IP address settings, use the Device Discovery Tool (page 41).**

To access the web interface, type the current IP address into the address bar of the web browser.

Address

To open a SSL-encrypted connection, type:

Address

You will be prompted to accept a certificate. Accept the NTI certificate.

A "Login Page" will appear.

The screenshot displays the web interface login page for an NTI device. At the top left is the NTI Network Technologies logo. On the top right, it shows 'Unit: sm-mxn-4k\_test' and 'Model: SM-16x16-4K' with an 'Uptime: 3 hours, 11 mins'. Below this is a navigation bar with 'Home' and 'Login' links. A 'Support' button is on the left. The main heading is 'Login'. The login form is titled 'Enter login credentials' and contains two input fields: 'Username' with the value 'root' and a placeholder 'Enter the username to log in with', and 'Password' with masked characters '\*\*\*' and a placeholder 'Enter the associated password'. A 'Login' button is located at the bottom left of the form. In the bottom right corner, there is a 'goalhead WEB SERVER' logo. The footer contains the copyright notice: 'Copyright © 2018 Network Technologies Inc. All rights reserved.'

Figure 7- Web interface Login page

### Enter the Password

The cursor will be flashing inside the username box. Enter the administrative username (this cannot be changed), then enter the default password:

**User Name = root** (lower case letters only)

**Password = nti** (lower case letters only)

To change the password, see page 33.

If you are not the "root" user, access to the VEEMUX may be limited. Contact the VEEMUX administrator for your individual username and password.

For information on setting up as many as 15 additional users, see page 33.

**Note: The browser must be configured to accept cookies in order for the user to successfully make use of the web interface.**

With a successful login, the main menu and Video Switch page will appear.

## Main Menu

The VEEMUX main menu provides control over all functions of the switch. The administrative menu includes options not available to other users with limited privileges.



When logged in a user without administrative privileges, only the SWITCH, LOGOUT, and SUPPORT menu options will be available.

For more on user management, see page 33.




Figure 8- Administrator Menu

(User Main Menu)

NTI NETWORK TECHNOLOGIES INCORPORATED

Unit: sm-mxn-4k\_test Model: SM-16x16-4K Uptime: 3 hours, 15 mins

Home > Video Switch Connections

Video Switch

Sort Ports by: Number Name Stored Configurations Load Save 0 Legend Active Connection Connection to be applied

Inputs	Outputs															
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
Port01 (1)																
Port02 (2)																
Port03 (3)																
4k pc (4)																
Port05 (5)																
Port06 (6)																
Port07 (7)																
Port08 (8)																
Port09 (9)																
Port10 (10)																
Port11 (11)																
Port12 (12)																
1080 pc (13)																
Port14 (14)																
Port15 (15)																
4k bluray (16)																

Note: Click an Input to Set All Outputs to that Input.

Submit Clear Changes

Copyright © 2018 Network Technologies Inc. All rights reserved.

Figure 9- Main menu and Video Switch page

From the menu the administrative user can choose from several links to either view the status of the switch or change the configuration of it. As described on the following pages, each link will enable different areas of control.

## Video Switch Page


The Video Switch page (Figure 9) displays the active connections (shown in orange) and enables the user to control the video connections of the VEEMUX. Up to 100 different connection configurations can be saved and later recalled by any connection method. Scanning Sequences (page 31) for each output can also be enabled.

**Note:** *Changes made using the keypad (page 8) or by another user through the web interface will be updated automatically to your browser every 10 seconds.*

**Note:** *In the 32x32 model, video matrix configuration 0 will be automatically loaded each time the VEEMUX is powered-up.*

**Note:** *In the 16x16 model, the last loaded video matrix configuration will be automatically loaded when the VEEMUX is powered-up.*

**To change a connection**, click on the radio button (square image with circle in the center) that intersects the input and output columns. A black dot will be placed in the circle to indicate the selection. Then press the **Submit** button. The display will be reloaded with the selections changed to orange to indicate they are now active. Multiple connections can be changed simultaneously.



**To quickly clear the selected radio buttons** press the **Clear Changes** button. This will only work if the **Submit** button has not already been pressed with the selections made.

**To quickly connect all outputs to a single input**, click on the desired input.

**FYI:** See page 32 for an example of using the *Outputs Scanning Sequences* feature.

**To save a configuraton**, from the **Stored Configurations** user interface, use the drop-down list to select the desired slot (numbers 0-99) to save the active configuration into and press the **Save** button.



**Note:** *This will save the currently active configuration on the VEEMUX and the EDID configuration (page 34). If changes have been made in the web interface without first pressing the Submit button, those changes will not yet be part of the active configuration.*

**Note:** *If changes to the active configuration have been made by another user prior to saving the current connection selections, the changes made by the other user will be saved as the configuration.*

The webpage configuration that loads after a **Save** is the configuration that was actually saved.

**To load a saved configuration**, from the **Stored Configurations** user interface, use the drop-down list to select the desired configuration. Then press the **Load** button. The VEEMUX will make the connections and the screen will refresh to show the connections associated with that configuration selection. This also loads the saved EDID configuration (page 34). The loaded configuration number will remain in the number block, to indicate the configuration that has been loaded and is present.

**To blank the video to a specific output**, click the box to the right of "Blank" that corresponds with the desired output to place a checkmark in it. The video going to that output will be disabled.

**To enable the scanning sequence configured for an output**, configure the automatic scanning sequence of inputs that should be viewed at the output (see page 31) and then click the box to the right of "Sequence Enabled" that corresponds with the desired output to place a checkmark in it. The video viewed from that output will switch from input to input according to the configured sequence.

## Administration

- Switch
- Administration
  - System
  - Network
  - Video Input Names
  - Video Output Names
  - Scanning Sequence
  - User Config
  - EDID Options
  - EDID Mix Settings
  - Firmware
- Standby
- Logout
- Support
- Reboot


The Administration section provides links to pages for all configuration options in the VEEMUX switch. Only the user ROOT and users with administrative privileges have access to this section. The administration section is broken up into 10 topics:

System	Assign the switch name and serial port communication settings
Network	Assign all network settings for connection to LAN
Video Input Names	Assign port names to each cable connection from video sources for easy reference
Video Output Names	Assign port names to each cable connection from display devices for easy reference
Scanning Sequence	Assign dwell times for each input as it is assigned to each output's scanning sequence
User Config	Add, edit, and delete users and control user privileges
EDID Options	Configure how each input will receive EDID information
EDID Mix Settings	Select outputs/displays to be used for EDID mixing for each input
Firmware	Update the firmware as new versions become available

## System Configuration

On the System Configuration page, under Administration, fields are provided to assign a unique name to the VEEMUX, set the baud rate for serial communications, and the serial address to be used in RS232 commands.

After applying the desired settings, press “**Save**” to finish.



**Figure 10- System Configuration page**

**Download Configuration File** - To save VEEMUX configuration and DDC settings for a future reload or to save time in configuring multiple VEEMUX switches, the configuration file for the VEEMUX can be downloaded to your PC using “**Configuration Backup & Restore**”. Click on “**Download Configuration File**” to save the VEEMUX configuration to your PC.

**From your PC the downloaded configuration file can be edited using any text editor or html editor. Using an editor you can change settings, change IP address, etc. and then upload the result into an additional VEEMUX switch to save time.**

**Upload Config-** Click on the **Browse** button to browse to the file, click on “**Upload Config**”, and restore the VEEMUX to the configuration stored in the uploaded file.

**Restore Defaults-** Click on “**Restore Defaults**” to remove all user-configured settings and restore the VEEMUX to a factory default configuration.

**Note: Before restoring defaults, we recommend you download the existing configuration file to your PC.**

After applying the desired settings, press “**Save**” to finish.

## Network Configuration

ON the Network Configuration page, under Administration, the administrative user can configure the VEEMUX web interface connection. This will provide access to control of the VEEMUX from any web-accessible computer.

### Network Configuration

The screenshot displays the Network Configuration page, divided into two main sections: IP Settings and Server Settings.

**IP Settings:**

- Mode:** A dropdown menu is set to "Static". A callout box highlights this menu, showing options: "Static", "DHCP", "Static", and "Disable".
- Method of acquiring IP settings:** This label is associated with the Mode dropdown.
- IP Address:** The field contains "192.168.3.61". Below it, the text "Statically assigned IP address" is displayed.
- Subnet Mask:** The field contains "255.255.255.0". Below it, the text "Statically assigned subnet mask" is displayed.
- Default Gateway:** The field contains "192.168.3.3". Below it, the text "Statically assigned default gateway" is displayed.
- Preferred DNS:** An empty text input field. Below it, the text "Statically assigned preferred name server" is displayed.
- Alternate DNS:** An empty text input field. Below it, the text "Statically assigned alternate name server" is displayed.

**Server Settings:**

- Enable Telnet:** A checkbox is unchecked. Below it, the text "Enable access to this device via telnet" is displayed.
- Allow HTTP Access:** A checkbox is checked. Below it, the text "Allow access via standard (non-secure) HTTP requests" is displayed.
- HTTP Port:** The field contains "80". Below it, the text "Port for standard HTTP requests" is displayed.
- HTTPS Port:** The field contains "443". Below it, the text "Port for HTTPS requests" is displayed.
- Web Timeout:** The field contains "600". Below it, the text "Minutes after which idle web users will be logged out (maximum: 32000; 0 disables idle logout)" is displayed.

Figure 11- Network Configuration page

**Mode** – Choose between Static IP assignment, DHCP (dynamic IP assignment) or Disable the Ethernet port entirely.

**IP Address-** If using Static IP assignment, enter a valid IP address to use

**Subnet Mask-** Enter a valid subnet mask value

**Default Gateway-** Enter a valid gateway address

**Preferred DNS-** Enter a valid Domain Name Server address (not required)

**Alternate DNS-** Enter a valid alternate Domain Name Server address if desired (not required)


This change will take a few seconds and automatically redirect the user to the IP address specified.

If telnet is going to be used to control the VEEMUX, place a checkmark in the “Enable Telnet” block.

If you wish to disable non-secure web access to the VEEMUX, remove the checkmark from “Allow HTTP Access”. With this box empty, only secure shell web access will be allowed.

A standard port number can be assigned for the HTTP (non-secure) and HTTPS (secure) ports, numbers ranging from 0-65535. Default HTTP port is 80, and default HTTPS port is 443.

The Website Timeout option controls how long an inactive web connection will stay logged in. The range is 0-3200 minutes (0 disables it). Any change to the Website Timeout configuration takes effect immediately.



**Figure 12- Network Configuration Page (continued)**

## X509 Certificate

The VEEMUX is designed to be configurable with secure access to the web interface controls. The VEEMUX is pre-loaded with a generic X509 Server Certificate. If you wish to provide your own X509 Server certificate, the Server certificate must be uploaded to the VEEMUX. The Server certificate and key must be combined into a single file (“PEM” format). For instruction to create your own certificate, see page 48 for more information.

**Browse** to the Server certificate file and select it. Then load using the button “**Upload Server Certificate and key**”.

**Note: The key used should not be password protected.**

## X509 Certificate Authority

A Certificate Authority (CA) needs to be used to sign the server certificate describe above. This Certificate Authority can be created as a self-signed certificate in “CRT” format. It can also be given to you by an external Certificate Authority in “CRT” or “PEM” format.

For https to work properly, you must load the certificate of your CA onto the VEEMUX. Use the “**Choose File**” button to browse to the file containing the CA certificate (which may also contain an intermediate certificate) and select it. Then click on the “**Upload CA certificate**” button. Please see page 48 for more information.

The “**Restore default certificate**” button will restore the unit’s default self-signed certificates if needed.

*Note: HTTP access can be enabled/disabled from web page under Administration -> Network -> Server Settings -> Allow HTTP Access (page 26). Do not disable http access until you verify certificate verification works properly for https connection. HTTP connection will allow you to change any settings if a wrong certificate is uploaded. Once HTTPS client certificate validation is verified to be working properly, disable HTTP access for security.*

After loading your own Server Certificate, **reboot the VEEMUX for this certificate to take effect.**

Press the **“Save”** button to save any changes made.



## Video Input Names

From the Administration menu, the Video Input Names page can be displayed. This page enables the administrative user to change the name of the input ports displayed on the Video Switch page.

**Video Input Names**

<b>Port1.</b>	Port01 Name for Input port 1
<b>Port2.</b>	Port02 Name for input port 2
<b>Port3.</b>	Port03 Name for input port 3
<b>Port4.</b>	4k pc Name for input port 4
<b>Port5.</b>	Port05 Name for input port 5
<b>Port6.</b>	Port06 Name for Input port 6
<b>Port7.</b>	Port07 Name for input port 7
<b>Port8.</b>	Port08 Name for input port 8
<b>Port9.</b>	Port09 Name for input port 9
<b>Port10.</b>	Port10 Name for Input port 10
<b>Port11.</b>	Port11 Name for input port 11
<b>Port12.</b>	Port12 Name for input port 12
<b>Port13.</b>	1080 pc Name for input port 13
<b>Port14.</b>	Port14 Name for Input port 14
<b>Port15.</b>	Port15 Name for input port 15
<b>Port16.</b>	4k blueray Name for input port 16

Save    Reset

**Figure 13- Video Input Names page**

To change an Input Name, enter the name of the port for the desired input port number, and press **“Save”**.

If you make changes and change your mind and want to return the names back to what they were before changing them, press **“Reset”**. This must be done before pressing the **“Save”** button, or changes will not be able to be reversed.

## Video Output Names

From the Administration menu, the Output Names page can be displayed. This page enables the Administrator to change the names of the output ports displayed on the Switch page.

### Video Output Names

Video Output Names	
User1.	<input type="text" value="Output01"/> Name for output port 1
User2.	<input type="text" value="Output02"/> Name for output port 2
User3.	<input type="text" value="Output03"/> Name for output port 3
User4.	<input type="text" value="4k mon"/> Name for output port 4
User5.	<input type="text" value="Output05"/> Name for output port 5
User6.	<input type="text" value="Output06"/> Name for output port 6
User7.	<input type="text" value="Output07"/> Name for output port 7
User8.	<input type="text" value="Output08"/> Name for output port 8
User9.	<input type="text" value="Output09"/> Name for output port 9
User10.	<input type="text" value="Output10"/> Name for output port 10
User11.	<input type="text" value="4k TV"/> Name for output port 11
User12.	<input type="text" value="Output12"/> Name for output port 12
User13.	<input type="text" value="Output13"/> Name for output port 13
User14.	<input type="text" value="dell 1200 mon"/> Name for output port 14
User15.	<input type="text" value="Output15"/> Name for output port 15
User16.	<input type="text" value="Output16"/> Name for output port 16

Figure 14- Video Output Names page

To change an Output Name, enter the name of the port for the desired output port number, and press "**Save**".

If you make changes and change your mind and want to return the names back to what they were before changing them, press "**Reset**". This must be done before pressing the "**Save**" button, or changes will not be able to be reversed.

## Scanning Sequences

From the Administration menu, the Scanning Sequence page can be displayed. The Scanning Sequence page displays the configuration of an automatic switching sequence from input (video source) to input for each output (monitor).

The page displays:

- output number being configured
- the Scanning Sequence function status for that output
- the length of time in seconds (dwell time) that each input will be viewed when connected- the dwell time value ranges from 0-255 seconds

### Scanning Sequence

**Scanning Sequence**

Dwell Times for output: Output01 (1)

Sequence Enabled

Input	Dwell time (seconds)
<b>Port01 (1)</b>	<input style="width: 100px;" type="text" value="0"/> <small>Scan dwell time for input 1 - (0-255)seconds. 0=disable scan.</small>
<b>Port02 (2)</b>	<input style="width: 100px;" type="text" value="0"/> <small>Scan dwell time for input 2 - (0-255)seconds. 0=disable scan.</small>
<b>Port03 (3)</b>	<input style="width: 100px;" type="text" value="0"/> <small>Scan dwell time for input 3 - (0-255)seconds. 0=disable scan.</small>
<b>4k pc (4)</b>	<input style="width: 100px;" type="text" value="0"/> <small>Scan dwell time for input 4 - (0-255)seconds. 0=disable scan.</small>
<b>Port05 (5)</b>	<input style="width: 100px;" type="text" value="0"/> <small>Scan dwell time for input 5 - (0-255)seconds. 0=disable scan.</small>
<b>Port06 (6)</b>	<input style="width: 100px;" type="text" value="0"/> <small>Scan dwell time for input 6 - (0-255)seconds. 0=disable scan.</small>
<b>Port07 (7)</b>	<input style="width: 100px;" type="text" value="0"/> <small>Scan dwell time for input 7 - (0-255)seconds. 0=disable scan.</small>
<b>Port08 (8)</b>	<input style="width: 100px;" type="text" value="0"/> <small>Scan dwell time for input 8 - (0-255)seconds. 0=disable scan.</small>
<b>Port09 (9)</b>	<input style="width: 100px;" type="text" value="0"/> <small>Scan dwell time for input 9 - (0-255)seconds. 0=disable scan.</small>
<b>Port10 (10)</b>	<input style="width: 100px;" type="text" value="0"/> <small>Scan dwell time for input 10 - (0-255)seconds. 0=disable scan.</small>
<b>Port11 (11)</b>	<input style="width: 100px;" type="text" value="0"/> <small>Scan dwell time for input 11 - (0-255)seconds. 0=disable scan.</small>
<b>Port12 (12)</b>	<input style="width: 100px;" type="text" value="0"/> <small>Scan dwell time for input 12 - (0-255)seconds. 0=disable scan.</small>
<b>1080 pc (13)</b>	<input style="width: 100px;" type="text" value="0"/> <small>Scan dwell time for input 13 - (0-255)seconds. 0=disable scan.</small>
<b>Port14 (14)</b>	<input style="width: 100px;" type="text" value="0"/> <small>Scan dwell time for input 14 - (0-255)seconds. 0=disable scan.</small>
<b>Port15 (15)</b>	<input style="width: 100px;" type="text" value="0"/> <small>Scan dwell time for input 15 - (0-255)seconds. 0=disable scan.</small>
<b>4k bluearay (16)</b>	<input style="width: 100px;" type="text" value="0"/> <small>Scan dwell time for input 16 - (0-255)seconds. 0=disable scan.</small>

**Figure 15- Scanning Sequence page**

The output selection at the top of the page can be changed to any output to display the Scan Sequence Input dwell time values for that output.

The inputs and the amount of time that each will be viewed (0-255 seconds) can be set to cycle sequentially for each connected output. If an input is set to 0 seconds, that input will not be viewed and will be skipped from the scanning sequence. To include an input in the sequence, enter a dwell time period from 1-255 seconds, and press **“Save”**.

If you make changes and change your mind and want to return the values back to what they were before changing them, press **“Reset”**. This must be done before pressing the **“Save”** button, or changes will not be able to be reversed.

To enable the scanning sequence for the output shown, place a checkmark in the **“Sequence Enabled”** block.

*Tip: To quickly enable the scan sequence for multiple outputs, use the “Sequence Enable” blocks found on the Switch Page (page 18).*

*Note: If only one input has a dwell time value entered, then the output connection to that input will not end when the Scanning Sequence is enabled.*

**Example of using Outputs Scanning Sequences**

**Problem:** A synchronous scan is desired for all outputs with a dwell time of 3 minutes per input, and no two outputs should be looking at the same input at any given time.

**Solution:**

1. Set the dwell time for all inputs listed in each output at 180 seconds (3 minutes). Press **“Save”** each time changes are made to the selected output. .
2. Go to the Video Switch page (page 18) and set each output to an input of the same number (1 to 1, 2 to 2, 3 to 3, etc..). Click on **“Submit”** at the bottom of the Video Switch Page to submit selections and establish a connection and starting point for the scanning sequence. (Blocks shown in yellow in the third image indicate connections made.)
3. Click on the **“Sequence Enabled”** box for each output (from the Video Switch Page).
4. Click on **“Submit”** again to begin the scanning sequence for each output.

From the moment the configuration is submitted, a synchronous scan will begin on all outputs. Each output will connect to its respective input for 3 minutes. After 3 minutes, the outputs will each switch to the next consecutive input and remain connected for 3 minutes. This cycle will continue indefinitely until sequencing is disabled.

**Scanning Sequence**

Scanning Sequence

Dwell Times for output: Output1 (1)

Sequence Enabled

Input	Dwell time (seconds)
Port1 (1)	180
Port2 (2)	180
Port3 (3)	180
Port4 (4)	180

Step 1- setup dwell times

Sort Ports by:	Stored Configurations	Legend
Port Number	Port Name	Active Connection
Load	Save	0
		Connection to be applied

Step 2- setup starting point for scan and click “Submit”

Inputs	1	2	3	4	5	6	7	8
Port1 (1)	●	○	○	○	○	○	○	○
Port2 (2)	○	●	○	○	○	○	○	○
Port3 (3)	○	○	●	○	○	○	○	○
Port4 (4)	○	○	○	●	○	○	○	○
Port5 (5)	○	○	○	○	●	○	○	○
Port6 (6)	○	○	○	○	○	●	○	○
Port7 (7)	○	○	○	○	○	○	●	○
Port8 (8)	○	○	○	○	○	○	○	●

Sequence Enabled

Output5

Output6

Output7

Output8

Step 3- enable scanning sequences and click “Submit”

Step 4- Click on “Submit” to begin

Sort Ports by:	Stored Configurations	Legend
Port Number	Port Name	Active Connection
Load	Save	0
		Connection to be applied

Step 4- Click on “Submit” to begin

Inputs	1	2	3	4	5	6	7	8
Port1 (1)	●	○	○	○	○	○	○	○
Port2 (2)	○	●	○	○	○	○	○	○
Port3 (3)	○	○	●	○	○	○	○	○
Port4 (4)	○	○	○	●	○	○	○	○
Port5 (5)	○	○	○	○	●	○	○	○
Port6 (6)	○	○	○	○	○	●	○	○
Port7 (7)	○	○	○	○	○	○	●	○
Port8 (8)	○	○	○	○	○	○	○	●

Sequence Enabled

Output5

Output6

Output7

Output8

Note: Click an Input to Set All Outputs to that Input.

Submit Clear Changes

## User Config

From the Administration menu, select the User Config to display a list of the users that have been configured on the VEEMUX.

- To add a user, select “Add New User”.
- To change the configuration of a user, select the Username, or “Edit”.
- To delete a user, select “Delete” for that user.

### Users

Users				
Num.	Username	Enabled	Admin	Action
1	<a href="#">root</a>	yes	yes	<a href="#">Edit</a>
2	<a href="#">user1</a>	yes	no	<a href="#">Edit</a> <a href="#">Delete</a>

[Add New User](#)

Figure 16- Users page

Whether you add a user, or edit a user, the “Configure User” page will open. If this is a new user being added, enter a user name, decide if the user should have administrative privileges or not, enable their access to the VEEMUX (or not), and assign a password.

- Usernames and passwords are case sensitive.
- Usernames can be from 1 to 16 characters in length and can be alphabetical or numeric.
- Passwords can be from 5 to 16 characters in length and can be alphabetical or numeric.

**Note:** A password must be entered for the user to be enabled, even if the “Enable” block is checked and the user is saved without a valid password being entered.

## Configure User

**Account Settings**

<b>Username</b>	<input type="text" value="user1"/> <small>The username for this user</small>
<b>Admin</b>	<input type="checkbox"/> <small>Grant this user administrative privileges</small>
<b>Enabled</b>	<input checked="" type="checkbox"/> <small>Users can only access the system if their account is enabled</small>
<b>Password</b>	<input type="password" value="••••••"/> <small>The user's password to login to the system (for local authentication)</small>
<b>Confirm</b>	<input type="password" value="••••••"/> <small>Confirm the entered password</small>
<b>Title</b>	<input type="text"/> <small>The user's title within the company</small>
<b>Department</b>	<input type="text"/> <small>The user's department within the company</small>
<b>Company</b>	<input type="text"/> <small>The name of the user's company</small>

Figure 17- User configuration page

After making any changes, be sure to click “Save”.

## EDID Options

From the Administration menu, the EDID Options page can be displayed. EDID enables the video source to get resolution information from the display device. This enables the video source to automatically select the optimal resolution for the display by receiving, at power up, information from the display device concerning its resolution specifications.

### EDID Options

EDID/HotPlug Options

Input	EDID Option					Hot Plug Option	HDCP Option
	Default 1	Default 2	Stored EDID	Load from output	Mixed		
Port01	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/> 1	<input type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>
Port02	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/> 2	<input type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>
Port03	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/> 3	<input type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>
Port04	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/> 4	<input type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>
Port05	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/> 5	<input type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>
Port06	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/> 6	<input type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>
Port07	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/> 7	<input type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>
Port08	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/> 8	<input type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>
Port09	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/> 9	<input type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>
Port10	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/> 10	<input type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>
Port11	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/> 11	<input type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>
Port12	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/> 12	<input type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>
Port13	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/> 13	<input type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>
Port14	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/> 14	<input type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>
Port15	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/> 15	<input type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>
Port16	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/> 16	<input type="radio"/>	<input type="checkbox"/>	<input type="checkbox"/>

Update EDID Options on Power cycle and on loading Stored Video Config.

Note: To save above EDID Options to other stored Video Configurations, use "Save" button in "Stored Configurations" on Video Switch page

**Store EDID to Input Port**

**Figure 18- EDID Options page**

EDID information can be provided to the video source by the VEEMUX as follows:

**Default1-** The video source on the input port will receive EDID information from the VEEMUX through an onboard table of values. The values for Default 1 support computer monitors. The factory default value is 1920x1080@60Hz(1080p).

**Default2-** The video source on the input port will receive EDID information from the VEEMUX. The value for Default 2 is 3840x2160@60Hz(UHD)

**Stored EDID (feature only in 16X16 model)-** The video source on the input port will receive the stored EDID that is stored on this Input Port by user. Refer 'Store EDID to Input Port' section on next page.

**Load from Output-** select the radio button for this option and enter the output number associated with the monitor that the CPU should get its EDID information from.

**Mixed-** The video source on the input port will receive EDID information that is common to the outputs selected on the "EDID Mix" page (page 37) for that input.

**Update EDID Options on Power cycle and on Load Stored Video Config-** place a checkmark in the box to refresh EDID data stored in the VEEMUX each time the VEEMUX is power-cycled or when a stored configuration (page 24) that includes this EDID configuration is loaded. The EDID data will be updated based on the configuration on this page.

**Save and Store to Video Configuration 0-** press to save the EDID Configuration settings to Video Configuration 0 so that when the VEEMUX is power cycled and the "Update EDID Options on Power Cycle...." (above) is checked, the EDID Configuration will be loaded as configured above.

**Modify Default1 EDID with User1 EDID**- click this button to load the EDID information to “Default1” from the video display connected to Output 1.

**Modify Default1 EDID with Factory Default**- click this button to restore “Default1” with factory supplied EDID information

Once any changes are made, press “**Save**” to have them take effect.

**Note:** *In order for the video sources to correctly receive the EDID information from the switch at boot-up, the switch must be powered-up before all attached video sources.*

**Store EDID to Input Port (feature only in 16x16 model)**- click this link to show settings to have input ports store EDID data from  
 A) any other Input Port or  
 B) any Output Port.

The "Stored EDID Vendor ID" will display the ID number of the EDID so you know what EDID is presently stored and available for use on the Input port.

Once this EDID is stored, the video source connected to the Input Port has the **option** to use this EDID no matter what is actually connected currently to its Output Port. To use this EDID for the video source on that Input Port, select the "Stored EDID" radio button under EDID Option.

Store EDID to Input Port					
Input Ports	Stored EDID Vendor ID	From Stored EDID of Another Input		From a Display Connected on Output	
Port01	VPI0401	Store Edid from Input	2	Store Edid from Output	1
Port02	VPI0401	Store Edid from Input	1	Store Edid from Output	1
Port03	VPI0401	Store Edid from Input	1	Store Edid from Output	1
Port04	VPI0401	Store Edid from Input	1	Store Edid from Output	1
Port05	VPI0401	Store Edid from Input	1	Store Edid from Output	1
Port06	VPI0401	Store Edid from Input	1	Store Edid from Output	1
Port07	VPI0401	Store Edid from Input	1	Store Edid from Output	1
Port08	VPI0401	Store Edid from Input	1	Store Edid from Output	1
Port09	VPI0401	Store Edid from Input	1	Store Edid from Output	1
Port10	VPI0401	Store Edid from Input	1	Store Edid from Output	1
Port11	VPI0401	Store Edid from Input	1	Store Edid from Output	1
Port12	VPI0401	Store Edid from Input	1	Store Edid from Output	1
Port13	VPI0401	Store Edid from Input	1	Store Edid from Output	1
Port14	VPI0401	Store Edid from Input	1	Store Edid from Output	1
Port15	VPI0401	Store Edid from Input	1	Store Edid from Output	1
Port16	VPI0401	Store Edid from Input	1	Store Edid from Output	1

Figure 19- Store EDID to Input Port options

## Hot Plug Options

Enabling “Keep HP On” (see **Figure 18**) ensures that PC does not re-read EDID from the VEEMUX when the input video port connection is changed to a different output video port regardless of whether the output port has a monitor connected. This applies when manually reconfiguring the video connection or when the device is in Scan mode. Physically disconnecting the output cable will still send a hot plug signal to the connected input port.

### Disable HDCP 2.2

Place a checkmark in the **Disable HDCP 2.2** box if you wish to disable the port's compatibility with HDCPv2.2.

Normally, if a video source senses that the VEEMUX is compliant, it will provide HDCP 2.2 compliant video. Then, provided the connected monitor is also HDCP 2.2 compliant, a picture will be displayed. If the monitor connected to a port is not compliant with HDCP 2.2 (i.e. only compliant with HDCP 1.4), then no picture would be displayed. To display a picture on a non-HDCP 2.2 compliant monitor, place a checkmark here to disable the feature for the source supplying video to that output port.

### Application Note:

To save and reuse the EDID information of any monitor please use the procedure below. This procedure will reuse the stored EDID even if a different monitor is connected or the matrix switch is rebooted.

1. Connect desired monitor to Output 1
2. Click “Modify Default 1 EDID with User1 EDID” in EDID Options menu
3. Now any Inputs with EDID Options set to “Default 1” will see this monitor's EDID going forward.

Optionally you can save this to a Stored Configuration (page 32) to send these saved EDID settings to the Inputs selected on the EDID Options page. Once the Stored Configuration is saved, it can be recalled at any time.



### EDID Mix

From the Administration menu, the EDID Mix page can be displayed. EDID Mix provides a means to decide which outputs (displays) will be used to provide EDID information to the selected input. The VEEMUX will compare EDID information from all selected outputs and provide EDID information that is common to those displays to the video source. If the "Mixed" option is desired for an input on the "EDID Options" page (page 34), settings of the EDID Mix for that input (below) should be selected and saved first.

If the EDID Mix configuration for an input is not configured and the "Mixed" option for the input is selected on the EDID Options page, a minimal default collection of EDID information will be provided to the video source.

## EDID Mix

**EDID Mix**

Select Input: Port01 (1) ▾

Select the Input port that will receive EDID information common to the outputs (displays) selected below.

Output	Select Output's to Mix
Output01 (1)	<input type="checkbox"/> Select output 1 to mix EDID data.
Output02 (2)	<input type="checkbox"/> Select output 2 to mix EDID data.
Output03 (3)	<input type="checkbox"/> Select output 3 to mix EDID data.
Output04 (4)	<input type="checkbox"/> Select output 4 to mix EDID data.
Output05 (5)	<input type="checkbox"/> Select output 5 to mix EDID data.
Output06 (6)	<input type="checkbox"/> Select output 6 to mix EDID data.
Output07 (7)	<input type="checkbox"/> Select output 7 to mix EDID data.
Output08 (8)	<input type="checkbox"/> Select output 8 to mix EDID data.
Output09 (9)	<input type="checkbox"/> Select output 9 to mix EDID data.
Output10 (10)	<input type="checkbox"/> Select output 10 to mix EDID data.
Output11 (11)	<input type="checkbox"/> Select output 11 to mix EDID data.
Output12 (12)	<input type="checkbox"/> Select output 12 to mix EDID data.
Output13 (13)	<input type="checkbox"/> Select output 13 to mix EDID data.
Output14 (14)	<input type="checkbox"/> Select output 14 to mix EDID data.
Output15 (15)	<input type="checkbox"/> Select output 15 to mix EDID data.
Output16 (16)	<input type="checkbox"/> Select output 16 to mix EDID data.
Disable Extended EDID	<input type="checkbox"/> <small>Use this for old DVI monitors which may not support extended EDID</small>

Save
Save For All Inputs

To save time and use the EDID information from the same outputs for all inputs (video sources), make the output selections above and then click on "Save For All Inputs".

Figure 20- EDID Mix page

## Update Firmware

From the Administration menu, the Update Firmware page can be displayed. The Update Firmware page shows the current version of the firmware and enables the Administrator to update the firmware to the latest version available.

## Update Firmware

Figure 21- Update Firmware page

**WARNING:** Failure to carefully follow these directions can permanently damage the VEEMUX. Please read these directions in full before continuing. Do not, under any circumstances, reset or power-down the VEEMUX while the firmware is being updated. Do not attempt to update the firmware if a power-failure is likely.

**Note:** The Firmware can only be updated from the non-secure (http) website. If you attempt to access this page from the secure (https) website, you will be automatically redirected to the non-secure site.

To update the firmware:

1. Contact NTI for the latest firmware file name `veemux-hd4k-vx-x.bin` (where x.x is the version number) and copy it to your computer.
2. On the Update Firmware page, in the “Update File” block, browse to the firmware file.
3. Press **Upgrade**.

**Note:** If an update is attempted using the wrong firmware for the section an error message will be received. No update will occur.

4. The VEEMUX will upload the firmware and then restart itself (this may take up to 4 minutes), logging out all connections. After the restart, approximately 4 more minutes, the VEEMUX will be ready to resume operation.

If a message appears stating that the Upload has failed, or that a non-fatal error has occurred:

1. Ensure that the file being uploaded is the NTI firmware file.
2. Repeat the process from step 2 above.

**Note:** The following message does not indicate that damage to the product has occurred.

If a message appears stating that there has been a fatal error:

1. **DO NOT RESET OR POWER-DOWN THE VEEMUX.**
2. Repeat the update process from the first step 2 above.
3. If you get another Fatal Error message, call NTI tech-support at 1-800-742-8324 or 330-562-7070.

**FYI:** The VEEMUX should continue to run normally unless it is reset. However, damage may have occurred to the web server firmware that will prevent the product from starting up correctly.

## Standby Mode

From the menu, the user can quickly place the VEEMUX in Standby Mode. When in Standby, the VEEMUX will still be powered-ON but all functions will stop. The VEEMUX will be in a power-saving ready-to-use state.




Figure 22- VEEMUX in Standby Mode

By simply selecting “Standby” from the side menu, the VEEMUX is placed in Standby Mode. When in Standby Mode, the VEEMUX will not provide video to any displays and cannot be manipulated further until standby is disabled.

Standby Mode can be disabled either

- by pressing “Disable Standby” through the web interface (above),
- by pressing any button on the front panel keypad
- by using the IR Remote control (optional)

## Logout

To quickly logout of the web interface, select “Logout” from the menu. You will immediately be logged out and presented with a login screen.




Figure 23- Logout of the VEEMUX web interface

## Support

The Support link on the menu drops down to two choices, **Manual** and **Downloads**.

The **Manual** link will open the pdf manual for the VEEMUX.

The **Downloads** link

(<http://www.networktechinc.com/download/d-4k-hdmi-matrix-switch.html> )

will open the firmware downloads page for the SM-16X16-HD4K Video Matrix Switch at NTI. From there you can see what versions of firmware are available and determine if the version in your VEEMUX is current or in need of an upgrade (page 38).




Figure 24- Support Tab

## Reboot

To quickly reboot the VEEMUX, select “Reboot” from the side menu. This will force the VEEMUX to power cycle its processor. A reboot will take approximately 45 seconds to occur. Refresh your browser and log back in to the VEEMUX as desired.




Figure 25- System Reboot

## DEVICE DISCOVERY TOOL

In order to easily locate the VEEMUX on a network, or to change network settings, the NTI Device Discovery Tool may be used. The Discovery Tool can be found at <http://www.networktechinc.com/download/d-4k-hdmi-matrix-switch.html> .

Unzip and save to a location on your PC. To open it just double-click on the file `NTIDiscover.jar` . This will open your browser and display the Device Discovery Tool page.


**Note:** The Device Discovery Tool requires the Java Runtime Environment (version 6 or later) to operate. Here is a [link](#) to the web page from which it can be downloaded.

**Note:** The computer using the Discovery Tool and the VEEMUX must be connected to the same physical network in order for the Device Discovery Tool to work.

### Network Technologies Inc Device Discovery Tool

- **START**
  - When you load this page, the NTI Device Discovery Applet should load. Accept the Certificate to allow this applet access to your network. Press the button entitled **Detect NTI Devices** to start the discovery process. After a short time, the tool will display all NTI devices on your network, along with their network settings.

**Note:** Do not close this page while the NTI Discovery Tool is running. Close the NTI Device Discovery Application first, **then** this webpage.
- **How To Use the Discovery Tool**
  - **To Change A Device's Settings**, within the row of the device whose setting you wish to change, type in a new setting and press the **Enter** key or the **Submit** button on that row. You can also press the **Submit All** button to submit all changes at once.
  - **To Refresh the list of devices**, press the **Refresh** button.
  - **To Blink the LEDs of the unit**, press the **Blink LED** button (This feature not supported on all products). The **Blink LED** button will change to a **Blinking...** button. The LEDs of the unit will blink until the **Blinking...** button is pressed, or the NTI Device Discovery Application is closed. The LEDs will automatically cease blinking after 2 hours.
  - **To Stop the LEDs of the unit blinking**, press the **Blinking...** button. The **Blinking...** button will change to a **Blink LED** button.



**Figure 26- Device Discovery Tool page**

Use the Device Discovery Tool to display all NTI VEEMUXs on your network, along with their network settings. Follow the instructions on the Device Discovery Tool page to use the tool and to change the device settings if so desired.



The "Blink LED" button is not supported on this product.

## INFRARED REMOTE CONTROL

The IRT-UNV Infrared Remote Control (**optional- sold separately**) allows the user to remotely and intuitively control up to 15 NTI SM-16X16-HD4K video matrix switches, providing the ability to route connections, save and recall switch configurations, and put the switch into Standby.

**Features:**

- Routing of video signals
- Ability to switch one input to all outputs
- Scroll through inputs for a single output by using the Input +/- keys (similar to changing channels)
- Automatically scan through all channels for a single output
- Save or Recall up to 10 matrix switch preset configurations
- Control up to 15 NTI switches (systems) with a single remote
- Put the switch in Standby

## Materials

**Materials supplied with the IRT-UNV:**

- NTI IRT-UNV Infrared Remote Control
- 2- AAA Batteries (installed)

## Buttons




The IRT-UNV Infrared Remote Control user interface consists of a keypad with 29 buttons. The buttons have the following functions:

- **Numerical Values (0-9)**
  - Selects port numbers (for IN, OUT)
  - Selects memory locations (for saved configurations)
- **\* (Asterisk)**
  - Pressed to select all outputs
- **OUT**
  - Pressed to indicate an output port selection
- **IN**
  - Pressed to indicate an input port selection
- **IN +/-**
  - Cycles through input ports (up or down), connecting to each one (similar to changing channels)

**Note: This affects only the selected output port**



- **SAVE**
  - Pressed to save the current switch configuration (port connections and volume settings)
  - Up to 10 configurations can be saved (0-9)
- **RECALL**
  - Pressed to recall a switch configuration (port connections and volume settings)
  - Up to 10 configuration can be recalled (0-9)
- **SYS**
  - Pressed to select the desired NTI system to be controlled
  - Only used when controlling multiple systems
  - Must be followed by a system number: 1-15
- **ENTER**
  - Pressed to immediately accept the command (normal delay is approx. 5 seconds).
- **ESC**
  - Pressed to cancel the current command

**Note: If the command has not yet been accepted, all button presses in the command sequence will be cleared**

- **Standby**  Pressed to put the unit into or out of standby mode
- **VIDEO**  **THIS BUTTON IS NOT USED FOR THIS PRODUCT**
- **BLANK Video** 
  - Turns OFF Video for the selected output
  - Can be used with \*(Asterisk button) to turn OFF video for all outputs
  - Video will be turned ON by pressing the Blank Video button again, or by switching ports

**Note: Blank and Un-Blank commands are applied only to the selected output**



- **AUDIO**  **THIS BUTTON IS NOT USED FOR THIS PRODUCT**
- **VOL +/-** **THIS BUTTON IS NOT USED FOR THIS PRODUCT**
- **MUTE Audio**  **THIS BUTTON IS NOT USED FOR THIS PRODUCT**
- **SCAN**
  - Pressed to toggle the scan enable/disable feature for the selected port
  - Must be preceded by an output port number (1 or 2 digits), or the \* (Asterisk) button to toggle all ports

*Note: If the dwell time for a port is set for 0 seconds, it will not be scanned (page 31)*
- **PREV -THIS BUTTON IS NOT USED FOR THIS PRODUCT**

## Operation

Operation of the IRT-UNV is intuitive. The number of button presses required to complete any operation is kept to a minimum. This is accomplished using intelligent software within the NTI Matrix Switch. Additionally, the Matrix Switch allows for multiple ways for the user to complete the same operation – ensuring that the Remote will work as expected, regardless of who uses it.

## Changing Ports

The first, and most important operational use of the IR Remote is changing ports of the switch. This requires the selection of both input and output ports. There are several methods of control.

## Channel Surfing

The “IN +/-” and “SCAN” buttons can be used to surf through input port connections. However, since there are multiple outputs/users, the question becomes “which output connection is being changed?” As a result, it is required that an output be selected prior to using the “IN +/-” buttons.

The output port can be selected in two ways:

- by pressing the “OUT” button before selecting the output port number
- by pressing the “OUT” button after selecting the output port number

In both cases, the user must enter the output port number using the Numeric Keys (0-9). However, when the “OUT” button is pressed prior to selecting the port number, there will be a two (2) second delay after the last digit of the output port is entered that must expire before the output port is accepted. To avoid this delay, press the “ENTER” button to immediately accept the port number.

Once the output port has been accepted, there will be a five (5) second timeout, during which the user must press another button (“IN +,” “IN -,” or “SCAN”). Each subsequent press of “IN+” or “IN-” will renew the timeout, waiting for you to press it again (to advance or go back by one more Input channel). If no new command is sent to the switch before the timeout expires, the switch will forget the selected output, and pressing the “IN +/-” buttons will have no effect.

All output channels can surf inputs at once by pressing the “ \* ” button prior to pressing the “IN +/-” buttons.

### Examples:

Change connection of Output 1 from Input 1 to Input 3:

<OUT> + <1> + wait 2 seconds + <IN+> + <IN+>  
 <OUT> + <1> + <ENTER> + <IN+> + <IN+> (must press <IN+> within 5 seconds of pressing <ENTER>)  
 <1> + <OUT> + <IN+> + <IN+> (must press <IN+> within 5 seconds of pressing <OUT>)



## Jump To Input

With the output port selected, a user knowing the desired input port number can enter it using the Numeric keys (0-9). Just as with using the “OUT” button, pressing the “IN” button after the number will force the command immediately. If the “IN” button is pressed prior to the port number, the “ENTER” button must be pressed to avoid a two (2) second delay before the input port is accepted.

### Examples:

Quick method to change Output 1 from Input x (any) to Input 8:

<1> + <OUT> + <8> + <IN>

Quick method to change Output 12 from Input x (any) to Input 20:

<1> + <2> + <OUT> + <2> + <0> + <IN>

## Jump To Output

Users can also change ports by specifying the input port number first. Similar to selecting the output port first, the “IN” button can be pressed either before or after entering the port number. Once the input port has been selected, the output port can be selected, following the same format as “Jump to Input...”

Expiration of a five (5) second timeout will force the switch to forget the entered input port number.

### Example:

Quick method to change Input 1 from Output x (any) to Output 8:

<1> + <IN> + <8> + <OUT> (must enter the <x> + <OUT> command within 5 seconds of pressing <IN>)

## Connect All

It may be desirable to broadcast the video signals from one input to all of the outputs. In this situation, the user can quickly make all of these connections by using the “\*” (asterisk) button which selects all outputs. With the input port selected, pressing the “\*” button will immediately force the command to connect all output ports to the selected input.

### Example :

Connect all users to Input 2:

<2> + <IN> + <\*>

The “\*” button can also be pressed prior to selecting the input port. In this case, the command will take effect once the input port has been selected.

<\*> + <2> + <IN>

If no command is received before the five (5) second timeout expires, the switch will forget the “\*” key-press.

### **Save and Recall**

This video matrix switch provides the ability to save and recall up to 100 switch configurations. The switch configurations define the current port connections, volume control settings, and video blank status. The IRT-UNV IR Remote can be used to access these configurations by using the "SAVE" and "RECALL" buttons.

To save a configuration, press the "SAVE" button followed by Numeric key(s) 0-99 corresponding to the memory slot the configuration is to be saved in. After the numeric key(s) press the "Enter" button. If the "Enter" button is not pressed, after two seconds the function will timeout and the number entered will be saved as that configuration.

Configurations can be recalled in much the same manner. To recall, press the "RECALL" button followed by the numeric key (s) corresponding to the memory slot from which the configuration is to be recalled. After the numeric key(s) press the "Enter" button. If the "Enter" button is not pressed, after two seconds the function will timeout and the number entered will be recalled to the current configuration.

### **Multiple Switch Control**

All compatible NTI matrix switches will work with the same IRT-UNV IR Remote control. As a result, a user with multiple NTI matrix switches may find that, if the switches are installed too close together, both switches may respond to an IR command intended only for one switch. Or, the user may want to control multiple switches with a single remote, instead of having one remote per switch. To accommodate this situation, the IRT-UNV IR Remote provides the "SYS" button, which can be used to select the NTI switch to be controlled.

All switches will have the capability to allow the user to set the switch address (0-15). Each switch to be separately controlled must be set to a different address prior to using the Remote Control. With the addresses set, press the "SYS" button on the IRT-UNV, followed by a two digit number corresponding to the address of the matrix switch to be controlled.

Upon accepting the "SYS" command, the switch with the corresponding address will illuminate the "IR" LED and respond to all IR Remote commands and will blink the "IR" LED on the front of the switch for visual indication. All other switches will ignore any further commands, until the "SYS" button is pressed again. To select a new NTI switch to control, press the "SYS" button again and repeat the process.

### **Canceling a Command**

Considering the number of key presses required for some of the commands, it's possible that the user may inadvertently press an incorrect button. Should this happen, the user can press the "ESC" button to cancel a command. Provided the command has not been accepted by the system, pressing the "ESC" button will cause the switch to "forget" or "erase" all button commands from the current command sequence. Once the command sequence has been cancelled, the user can begin entering the command again.

## Technical Specifications For IRT-UNV

Number of Controllable Systems	Max: 15
Pushbutton Control	29 keys
Power supply	2x AAA Battery
Chassis material	Plastic
Approvals	RoHS

## Troubleshooting the IRT-UNV

PROBLEM	SOLUTION
IRT-UNV is not selecting outputs or inputs	<ul style="list-style-type: none"> <li>• Check battery</li> <li>• The IRT-UNV may be configured to control the wrong switch- see "Multiple Switch Control" above.</li> </ul>

## Troubleshooting the VEEMUX

PROBLEM	SOLUTION
VEEMUX will not boot up	<ol style="list-style-type: none"> <li>1. Make an RS232 connection to the VEEMUX as described on page 6.</li> <li>2. Set the terminal program to communicate at 115200bps.</li> <li>3. Power ON the VEEMUX and, as it is powering up, press and hold the &lt;Tab&gt; key until a boot prompt appears ( <b>VEEMUX&gt;</b> ) in the terminal program.</li> <li>4. At the boot prompt type the following:   <div style="text-align: center;"><code>VEEMUX&gt;nand erase config</code> and press the &lt;Enter&gt; key.</div> </li> <li>5. Power-cycle the VEEMUX. It should bootup and resume normal operation with all factory default settings restored.  <b>Any customized settings previously entered will be erased and will need to be re-entered.</b> </li> </ol>

## CREATION OF CUSTOM X509 CERTIFICATES

The VEEMUX SM-16X16-HD4K (and other sizes) is designed to be configurable with security to limit access to their web interface controls. The VEEMUX includes a default x.509 certificate. However, this procedure will help you create your own custom x.509 certificate to use with this feature. This procedure was created using CentOS and OpenSSL.

**Note: Do not disable access to the VEEMUX web interface using http before you verify that the https client authentication works properly (see last page).**

### I. Using Self-Signed Certificates for VEEMUX Series Products

We can use self-signed certificates to access VEEMUX products with HTTPS with a self-signed root certificate authority. In this procedure, our root certificate authority needs to be explicitly added to every PC as trusted authority, to access the product page.

#### 1. Creating a Self-Signed Certificate Authority using OpenSSL

An example SSL configuration file to use can be found here: <http://www.networktechinc.com/download/openssl.cnf>

When using this document, make a copy of the current default openssl configuration file and replace it with the file above.

##### a. Creating the Certificate Management Files and Directories

The following directories are made for organizing the files being used and generated. These directories are also used for other procedures in the document.

1. Create directory "ntiCA" in /usr/local/ssl for ntiCA certificate management and change to that directory. If you prefer, this directory name can be set to any other name like MyCompanyCA. Make sure the `openssl.cnf` file is edited to match the changes to the folder name. The `openssl.cnf` file can usually be found in /usr/local/openssl/openssl.cnf on local installations of OpenSSL.

```
# mkdir /usr/local/ssl/ntiCA
# cd /usr/local/ssl/ntiCA
```

Create the following directories in the ntiCA directory: **(The number sign (#) is the command prompt, not part of the command.)**

```
# mkdir CA
# mkdir server
# mkdir server/certificates
# mkdir server/requests
# mkdir server/keys
# mkdir user
# mkdir user/certificates
# mkdir user/requests
# mkdir user/keys
```

Perform the following commands in the ntiCA directory:

```
# cd /usr/local/ssl/ntiCA
# touch index.txt
# echo "01" > serial
```

##### b. Creating the CA Key and Certificate

The general process for creating a certificate includes:

1. Creating a private CA key
2. Creating a certificate request
3. Creating and signing a certificate from the certificate request

## 1. Create the private CA key:

```
# cd /usr/local/ssl/ntiCA
# openssl genrsa -out ./CA/ntiCA.key 2048
Generating RSA private key, 2048 bit long modulus
.....+++++
.....+++++
e is 65537 (0x10001)
```

## 2. Create the CA certificate signing request:

```
# openssl req -sha512 -new -key ./CA/ntiCA.key -out ./CA/ntiCA.csr
```

You are about to be asked to enter information that will be incorporated into your certificate request.

What you are about to enter is what is called a Distinguished Name or a DN.  
There are quite a few fields but you can leave some blank  
For some fields there will be a default value, (indicated by the characters "[ ]")  
If you enter '.', the field will be left blank.

```
-----
Country Name (2 letter code) [US]:US
State or Province Name (full name) [OH]:OH
Locality Name (eg, city) []:
Organization Name (eg, company) [NTI]:NTI
Organizational Unit Name (eg, section) []:
Common Name (eg, YOUR name) [NTI CA]:NTI CA
Email Address [sales@ntigo.com]:sales@ntigo.com
```

Please enter the following 'extra' attributes  
to be sent with your certificate request

```
. []:
. []:
```

## 3. Self-sign the CA certificate:

```
# openssl x509 -req -sha512 -days 3650 -in ./CA/ntiCA.csr -out ./CA/ntiCA.crt
-signkey ./CA/ntiCA.key
Signature ok
subject=C = US, ST = OH, O = NTI, CN = NTI CA, emailAddress = sales@ntigo.com
Getting Private key
```

## c. Verifying the CA certificate contents

At this point we have our self-signed CA certificate and our CA key, which will be used to sign the VEEMUX certificates that we create. To verify the certificate contents, use the following command:

```
# openssl x509 -in ./CA/ntiCA.crt -text
```

The output should look similar to this:

```
Certificate:
Data:
  Version: 1 (0x0)
  Serial Number:
    b2:ce:14:9d:bf:52:f5:1f
Signature Algorithm: sha512WithRSAEncryption
Issuer: C = US, ST = OH, O = NTI, CN = NTI CA, emailAddress = sales@ntigo.com
Validity
  Not Before: Dec  4 20:00:24 2018 GMT
  Not After : Dec  1 20:00:24 2028 GMT
Subject: C = US, ST = OH, O = NTI, CN = NTI CA, emailAddress = sales@ntigo.com
Subject Public Key Info:
  Public Key Algorithm: rsaEncryption
  Public-Key: (2048 bit)
  Modulus:
```

```
00:b0:43:2b:de:93:7b:ac:1f:24:96:9d:e9:98:26:
44:bc:cb:7e:04:ec:c2:64:da:60:59:a1:c8:b7:42:
52:04:b7:b2:91:b1:10:db:ea:04:25:52:14:8b:52:
a4:7f:5a:fc:08:65:c6:77:44:8b:48:27:71:68:00:
c2:09:a2:b4:4a:3d:f9:3c:f8:d0:69:24:e8:44:b8:
07:57:e1:57:2d:0e:9b:2f:3e:df:4c:71:00:45:bb:
ff:2d:a6:7f:11:2d:34:ca:f2:07:f5:79:f0:4f:9b:
d8:d3:ad:04:3b:3c:56:07:25:c1:be:fe:09:03:8a:
6e:4d:72:82:ad:67:22:2c:54:1b:d5:69:5b:2b:67:
1f:12:f5:98:ef:a4:10:1d:56:83:13:ca:8d:d7:2f:
c5:0a:da:d5:3b:30:25:9a:2c:6f:8c:94:c1:69:35:
e2:38:9b:1b:37:53:ff:d6:2d:3e:d9:1c:7a:03:b3:
71:a6:76:16:f4:eb:35:2a:f2:86:6f:40:d9:cc:6e:
59:31:ef:94:11:cf:cc:52:9d:eb:8e:06:69:67:ee:
86:98:b0:54:11:61:71:aa:ae:19:2a:f3:77:ce:95:
2c:a5:87:0d:10:16:b9:5e:88:c8:03:da:d9:6d:90:
3b:ca:4c:32:15:0c:ba:05:64:79:c7:4b:b0:7a:f5:
26:5d
```

Exponent: 65537 (0x10001)

Signature Algorithm: sha512WithRSAEncryption

```
9f:d2:50:61:36:f3:d9:b9:cb:39:5e:31:d6:2a:a8:e4:03:f0:
e0:65:4d:37:e0:60:cd:71:f5:5a:6d:7d:87:53:6e:2e:8b:3a:
f2:fb:73:fc:21:51:63:79:8a:2d:5d:a9:c2:a9:47:a1:b3:17:
9a:2e:5b:8a:7f:29:ab:08:cb:2f:52:70:26:2c:76:2d:2d:07:
81:cc:84:6f:59:db:f3:be:fe:77:dc:67:6b:5d:ff:b3:17:24:
bd:f3:c0:cc:83:10:d0:17:67:2d:e5:5b:4b:59:aa:80:fb:ec:
53:ed:e4:c5:0d:a1:0d:13:b3:0b:ee:a4:c2:f0:d2:a0:29:ef:
11:f5:6a:29:8b:46:ed:1a:64:2b:93:02:af:0d:7f:83:28:2c:
a2:11:2e:e6:fc:af:61:d2:df:eb:e2:c0:e2:46:6e:ef:51:6e:
e1:db:4f:d4:24:2b:6d:63:21:d0:3c:f2:02:6e:d0:63:10:bf:
1c:9c:bf:31:c8:74:cd:88:51:7b:cc:a6:8d:6d:c1:fb:5c:63:
8a:dc:74:de:5f:04:d2:2d:b0:5b:c7:65:06:37:c0:42:8d:87:
22:2e:2d:59:dc:89:6c:e4:32:fe:2f:88:da:42:50:6e:67:3e:
6c:7c:86:9b:f4:20:60:6b:26:c2:cd:0b:97:d8:e1:f5:f9:c1:
4c:32:6c:ab
```

-----BEGIN CERTIFICATE-----

```
MIIDLjCCAhYCCQCyzhSdv1L1HzANBqkqhkiG9w0BAQ0FADBMZQswCQYDVQGEwJV
UzELMAkGA1UECBMCT0gxDDAKBgNVBAoTA05USTEPMA0GA1UEAxMGTlRJIENBMR4w
HAYJKoZIhvcNAQkBFg9zYWxlcl0BudGlnby5jb20wHhcNMTgxMjA0MjAwMDIOWHcN
MjgxmjA0MjAwMDIOWjBZMQswCQYDVQGEwJVUzELMAkGA1UECBMCT0gxDDAKBgNV
BAoTA05USTEPMA0GA1UEAxMGTlRJIENBMR4wHAYJKoZIhvcNAQkBFg9zYWxlcl0Bu
dGlnby5jb20wggeiMA0GCSqGSIb3DQEBAQUAA4IBDwAwgGEKAOIBAQCwQyvek3us
HysWnemYJkS8y34E7MjK2mBZoci3QlIEt7KRsrDb6gQlUhsLUqR/WwvIZcZ3RitI
J3FoAMiJorRkPfk8+NBpJohEuAdx4VctDpsvPt9McQBFu/8tpn8RLTTK8gf1efBP
m9jTrQQ7PFYHJcG+/gkDim5NcoKtZyIsVBvVaVsrZx8S9ZjvpBadVoMTyo3XL8UK
2tU7MCWalG+MlMfPNeI4mxs3U//WLT7ZHHoDs3Gmdhb06zUq8oZvQnNmblkx75QR
z8xSneuOBmln7oaYsFQRyXGqrhkq83fOlSyLhw0QFrleiMgD2tltkDvKTDIVDLoF
ZHnHS7B69SZdAgMBAAEwDQYJKoZIhvcNAQENBQADggEBAJ/SUGE289m5yZleMdYq
qQD8OB1TTfgYm1x9VptfYdTbi6LovL7c/whUWN5iil1dqckPr6GzF5ouW4p/KasI
yy9ScCYsdi0tB4HMhG9Z2/O+/nfcZ2td/7MXJL3zwMyDENAXZy3lW0tZqoD77FPT
5MUNoQ0TswvupMLw0qAp7xHlaimLRu0aZCuTAq8Nf4MoLKIRLub8r2HS3+viwoJG
bu9RbuHbt9QkK21jIdA88gJu0GMQvxyvzvzHidM2IUXvMpoltwftcY4rcdN5fBNIt
sFvHZQY3weKNhyIuLVnciWzkMv4viNpCUG5nPmx8hvp0IGBrJsLNC5fy4fX5wUwy
bKs=
```

-----END CERTIFICATE-----

## 2. Creating a CA-Signed VEEMUX server Certificate (This will need to be done for each VEEMUX device.)

The procedure for creating a CA-Signed web server certificate is similar to that for creating the CA certificate except that the device certificate will be signed using the CA key rather than self-signing with a server-specific key.

- a. Create the web server private key using a fully qualified DNS name (or IP address).

```
# cd /usr/local/ssl/ntiCA
# openssl genrsa -out ./server/keys/your_device_fqdn_or_ipaddress.key 2048
Generating RSA private key, 2048 bit long modulus
.....++++++
.+++++
e is 65537 (0x10001)
```

b. Create the web server certificate signing request using the same fully qualified DNS name (or IP address) you used for the private key. **It is vitally important** that you set the Common Name value to the fully qualified DNS name of your web server because that's the value that a browser client will verify when it receives the web server's certificate.

```
# openssl req -sha512 -new -key ./server/keys/your_device_fqdn_or_ipaddress.key -
out ./server/requests/your_device_fqdn_or_ipaddress.csr
```

You are about to be asked to enter information that will be incorporated into your certificate request.

What you are about to enter is what is called a Distinguished Name or a DN.

There are quite a few fields but you can leave some blank

For some fields there will be a default value, (indicated by the characters "[ ]")

If you enter '.', the field will be left blank.

-----

```
Country Name [US]:US
State or Province Name [OH]:OH
Locality Name []:Aurora
Organization Name [NTI]:NTI
Organizational Unit Name []:
Common Name [NTI CA]:192.168.3.144
Email Address [sales@ntigo.com]:your_name@example.com
```

Please enter the following 'extra' attributes to be sent with your certificate request

```
. []:
. []:
```

c. Create a file defining the Subject Alternative Name. This extension file extensions.ext can be made with any text editor, and should be added to the /usr/local/ssl/ntiCA directory. This needs to be defined to know for what domains or IP addresses the certificate will be valid. Add the following lines to the **extensions.ext** file:

```
basicConstraints=CA:FALSE
subjectAltName=IP:<ip_address>
```

Replace "**<ip\_address>**" with the IP address you plan to use to access the device. Other options are available for specifying this. Below is an example using a DNS:

```
subjectAltName = DNS:server.example.com
```

d. Sign the web server certificate with the CA key:

```
# openssl x509 -req -in server/requests/your_device_fqdn_or_ipaddress.csr -CA
CA/ntiCA.crt -CAkey CA/ntiCA.key -CAcreateserial -out your_device_fqdn_or_ipaddress.pem -
days 1024 -extfile extensions.ext
```

```
Signature ok
subject=C = US, ST = OH, L = Aurora, O = NTI, CN = 192.168.3.144, emailAddress =
sales@ntigo.com
Getting CA Private Key
```

To verify the web server certificate contents, use the following command:

```
# openssl x509 -in your_device_fqdn_or_ipaddress.pem -text
```

Key values to look for are:

```
Subject CN=192.168.3.144
Issuer CN=NTI CA
```

### 3. Uploading a Self-Signed Certificate Authority to a VEEMUX Device

You should import the "ntiCA.crt" file located in the /usr/local/ssl/ntiCA/CA directory that is generated using this procedure into the VEEMUX. To import this file into the VEEMUX, you must log into its web interface.

On the VEEMUX Web Interface menu Under "Administration" select "Network". In X509 certificates, select "Choose File", select the CA certificate file ntiCA.crt, and click "**Upload CA certificate**".

#### 4. Uploading Server Certificate to a VEEMUX Device

The NTI VEEMUX web server expects the certificate and key as a single file in "PEM" format.

Use the following command to combine certificate and key file to a single file with extension "pem".

```
cat ./server/keys/your_device_fqdn_or_ipaddress.key your_device_fqdn_or_ipaddress.pem > server.pem
```

On the VEEMUX Web Interface menu Under "Administration" select "Network". In X509 certificates, select "Choose File", select the server certificate and key file, and click "Upload **Server certificate and key**".


The following is an example of what the **server.pem** file should look like:

```
-----BEGIN RSA PRIVATE KEY-----
MIIEowIBAAKCAQEAXmpFFvwbJymSP2Pos/+NIDQvmoIU4xv2FBZBu0rc+uRKF1D
y2VeFKlMufp2JXMTxSHXCOjyZgVVEH9jB1VORU6WRz2/6VG5HYDQFa8dptC9YJ2S
yRUA65T0bwsZCCHMfE6Qxk/1r en59rtckYpygz7/VdcNAhgcoLoIHR0JFTLw0NMF
MTt1kw1cNXTsBT//55jTYofba7qck1HpsRTPdwoHwaJnoyH9t/I/JnFdtJJu3JQN
qnA9G3pQdoi/J3Nug2CNKRSLJutBTAmLQsJjU1mwg4MvCxpWURATNOWNnngAhuX1
t694QVI8owZ+byciDUjGsmDr3GUQ4i6/97sdeQIDAQBAoIBAEHVle/xDVFwM3k
bBgRzsRetwJ3Vna5n8tq01K6RIiavE61JOPK/FKovjIQAusKGF0tFeI6sSKr+Ez8
iBn2Eayr4SzaJAUeOznQ7QvzQ1bcm/ji5wd/LDGMGFmtzVjmj6CXyE+y5siggfGx
woxKL4l2j13jdsy7q6G2hQ7Q72dzvt1EFRBAzvBdQ5LjPcRnXzXQ8ZGXCmUS/r09
IwwlXzpkUce0IDG27wqSFa7DSzwouq8gSkIGNxe643pBGFJYL0z4+00DYFiaete
izqNh9u1hgrwu6Avw0/Mt15icsdpZgtgQ6Az1/tcT5y89zKyanHETxho5jiov1Pi
+1YCyuo0cGyEA5jJXhAxcDMzDBSju1N8D1nyr87CSac7DEG40o251FBL93rUe62Cu
cPuyy8goFFKtmbxd1ldztxmQww+VMwX28jBSH81vexqgiYgty1dde/Ih6v94Ccu
nFioUw92BRwt7zf3y6AhrR2blfucBrNqsCDPCS7QuYKkp1wiCjZUNScgyEA2rUK
w8u3d0pFesJYttxv1BHSVLBN7wsACo2RC9qkevEPacjMmScZJpgiA6Jpwm1za9b
AFU1ZACTkHkw7gd8xb7HOjKcPH4FN+YO9SxEWUE/Xetznrv4vobPjBzZHHdG7cub
jvaYCDM6UUQSLPx1Up5RWuwnMAC6FdvJqkT14TScgyEA1LUo3v/ZbanRVHLCaZD
wk0Cnzj9hcsrZgkFiozmZzXter4dld7yNr2U1vILGyTy0F9GICEC38X1fwPn1YH
pzB0RUuIBLut0QjK92bWk56IPkF65CC2noccngce75KUNUBacTG7w0F0873kuba1
HG7Yaj11ZTscbs/nvB1EBuMCGyAXddaUplEbbjYwmm5VHzRHtVmsT651S9QuehK1
wbhwysmt/tgBsDjUd1KrVsJG8dJLxq+E4WfyNrTwo15IwhuLebe5XTPHDOHGyCF
QChc70is1IzkfB1kpvv0PzrEhXkr34TSdr0Rkp+ySSB+iaNRDpJ3IcFmcbTLPI
CVnuvQK8gCps6uXdhXJMD6wgeutq9gQQO80g+vtMWHmIuEXvW9ot+h+jCKTRmuz3W
S7MgNu1jPctusLig+exnUG8fxy4671Ck7nags1Dr0zGjPpiX2BZF5AhuoCwck1wc
3LwF4AnRw4VgCUSTBSzEIOSda1/4oqbz65Ry2ZpxYzn5jppfQqsc
-----END RSA PRIVATE KEY-----
-----BEGIN CERTIFICATE-----
MIID4TCCAsmgAwIBAgIJAJMjAtDg7g/ama0GCSqGSIb3DQEBCwUAMIGCMQswCQYD
VQQGEwJVUZELMAKGA1UECBMT0gxDZANBgNVBAcTBKBF1cm9yYTEhMB8GA1UECgYD
TmV0d29yayB1Zm9yb29yY29yY29yY29yY29yY29yY29yY29yY29yY29yY29yY29y
MA0GA1UEAxMGTlR3IENBMSUwIWIYKozIhvcNAQkBFhZqdXN0aw4uzmvycm1Abnrp
Z28uY29tMB4XDTE4MTIwMzE4MzZkZnloXDTIwMDkymjE4MzZkZnloWga1XCZAJBgNq
BAYTA1VTMQswCQYDVQIQIEwJPSDEPMA0GA1UEBXMGMQswYyB3JHmSEWHwYDVQKEXho
ZXR3b3JrIFRlY2hub2xvZ211cyBjbmMxZDASBgNVBAcT0vuz21uzwvyaw5nMRUw
EYwYDVQDEwXOTIuMTY4LjMunZEXJTAjBkgqhkig9w0BCQEWfmp1c3Rpb15mZXYy
aUBudGlnby5jb20wggEiMA0GCSqGSIb3DQEBAQUAA4IBDwAwggEKAoIBAQAQeQakv
+9ZsnkZI/Y+iz/40gNC+aghtjG/YUFkG7Stz65Ep/UPLZV4uqUy5+ny1cxPFIcDI
6PJmBVUQf2NvVU5FTpZHPb/pUbmFg0ovrx2m0L1gnZLJFRrpjPRVBjKIIcX8TPDG
T/wt6fn2u1yrinkDPv9V1w0CGBYguggdGgkVMvDQ0UwX03WRBvV1dNIFP/9LmNng
59trupyTuelJFM91Y4fBqoejIf238j8mcv20km7cha2qcd0be1B2iL8nc26DYI0q
tIsm60G1MCYTCwmNsbwCdgy9zG1zREBM05aecYCG5Fw3r3hBUjyJbn5vJyJ15MzK
Z2vcZRD1Lr/3ux15AgMBAAGjHjACMAKGA1UEdWUQCAAAdWYDVR0RBAGwBocEwKgd
RZANBgkqhkiG9w0BAQsFAAOCAQEAFM6WkCwdU1ARIKc8TM4BI9GMA7VEC+69Cgo
Gkiz4WBEYf1bc265uH7Lz+/z88rdf1xw9B5Xc2B2GCzCXPYwLCHfzpxbf6c7Kp2
bs20HzvCTG1uvwm+r51bjmqQZzUQVH5VMZP8ct7HboZbhtc6KwFRFIW5CSZ5u1ghn
tfxBEfiQGaR7wNTUEk9B4LJ3ghSNBYC+gPXOCQSK3taxq1ua5fx08/6QBULQqBA
Fz0sbstNc7INpqtK90ZUotw03HAnr+gzJb3i4XQK5BREu1CLh1ky6X36PX4hf1rh
rf6da7kdfkC0g3x6B1EJzR/Cmazfmutd/AKKpVFT25YKE78jMQ==
-----END CERTIFICATE-----
```

#### 5. Accepting a Self-Signed Certificate Authority as Trustworthy

##### How to add a Self-Signed Certificate Authority as a Trusted Root Certification Authority on Windows

The browsers must recognize and trust the Certificate Authority created. The following are directions for trusting the newly created CA.




1.Right click on "ntiCA.crt" on the PC. Choose "Install Certificate".







2. There will be a wizard to guide you through the next steps. Click "Next".




3. Click "Browse" and then.....



.....select "Trusted Root Certification Authorities"



4. Click "Finish" to complete.



5. You are done! Restart the preferred browser.

### **How to add a Self-Signed Certificate Authority as a Trusted Root Certification Authority on Mozilla Firefox**

Mozilla Firefox does not use Window's Certificate Authorities. For the Firefox browser to recognize your CA, do the following:

1. Open the Mozilla Firefox browser.
2. Type "about:preferences#privacy" in the URL field of the browser.
3. Under "Security" in the "Certificates" section, press the "View Certificates" button.
4. Navigate to the "Authorities" tab.
5. Select "Import"
6. Find your self-made CA and press "Open"
7. Select "Trust this CA to identify websites" and click "OK".
8. Restart the Firefox browser.

**Note that some of these directions may be slightly different for older versions of Firefox.**

## II. Using External CA Signed Certificates for VEEMUX Series Products

### 1. Creating a certificate signing request for External Certificate Authority

A Certificate Signing Request must be provided to an external Certificate Authority like DigiCert, Verisign, or Comodo.

The Certificate Signing Request should be made using the following command:

```
# mkdir thirdparty
# mkdir thirdparty/certificates
# mkdir thirdparty/keys
# openssl genrsa -out ./thirdparty/keys/server.key 2048
# openssl req -sha512 -new -key ./thirdparty/keys/server.key -out
./thirdparty/certificates/server.csr
```

Below is an example of a valid certificate signing request:

```
-----BEGIN CERTIFICATE REQUEST-----
MIIDGzCCAgMCAQAwgawXCZAJBgNVBAYTA1VMTQswCQYDVQQIEWJPSDEPMA0GA1UE
BxMGQXVyYb3JhMSEwHwYDVQQKEWh0ZXR3b3JrIFRlY2hub2xvZ211cyBjbmmFDAS
BgNVBAStC0Vuz21uzwvyaw5nMR8wHQYDVQQDEXZ3d3cubmV0d29ya3RlY2hpbmMu
Y29tMSUwIwYJKoZIhvcNAQkBFhZqdXN0aw4uzmvyemlAbnRpZ28uY29tMIIBjAN
BgkqhkiG9w0BAQEFAAOCAQ8AMIIBCgKCAQEazc1BU6EbjL4hnyj9uFM2E02qzTHR
c/OUL8kaoZZyExpnk3ekr1GwSTciv3hp4ZY+AlxuyOP5pzwWnIGxzBhgW0XybIgm
/IraRiEzrh8jw+kKUCjcbHP1DQXES7Ehx1MDonyTVEaIXF5Ya8RWJMXisrd4vTfc
ecm3zguq1HN4rmy4Uj4EN7fsDrT2Qppc1PKvFiFaFdwasi7GxA8q2Gffx5mfhpw
yb5qAPPx78f6wTYk/MeasUDVDC5DH10L87MfYkMLhc+1tLIOxUSku0NJYczuc/g0
0Auk+khgkH5gau9t831CTheI60kHswNR8P9eHSHT0o0U9XfuoywmpL6ByQIDAQAB
oCkwJwYJKoZIhvcNAQkOMRowGDAJBGNVHRMEAJAAMASGA1UdDwQEAwIF4DANBgkq
hkig9w0BAQ0FAAOCAQEAAQ2Es1PHsBrPIDwCLZ/9+4htCcgTyIXBb6A7TmVlMnZF
JcyC7/78np+jGhsMbM9Pgh6DjpcTuIgsSD1wzP9JLgq+5jKn3Lm6tSCGCZ7YYT
cf6VftPyCP5GknvqfzfTAPKESj40tIqM/gvyByQzD1CFL4FIghRrYxpbBgpBpj/
C9S1FZT5XjuS/ixbkm/06Gwz06H6US8PAFmTvIshaog6i9nhIBWug70e0jwBdnTb
JaqpAIF30rTbq/iKgXzYb4L9bowEyxvP/D1dox7vG9egbi4WjjjIhuossxFb7Q1J
ODH+cC7uALD5PhLaugg1hi8a1igt1Iuip1B1UztZcg==
-----END CERTIFICATE REQUEST-----
```

Upload your CSR to your Certificate Authority to get the certificate.

### 2. Uploading Server Certificate to a VEEMUX Device

The NTI VEEMUX device expects the certificate and key as a single file in "PEM" format.

The server certificate file with extension "pem" should be received by your external CA after submitting a certificate request. Get your server certificate in a .pem or .cer format. Copy your server certificate into another file and add the device key as shown below.

```

-----BEGIN RSA PRIVATE KEY-----
MIIeowIBAQAQEAyQ1pn1Rkr3r4w1Cj10jYrFw2+bxqv6wr otMyGfIRZaZkLo5J
1whYb/ufCX2Unc/H5X7wDa3gawr 6iJki/dvf8X16gpPHi crWR+wFAiRs/D7z+B/ew
iam5vqDMTW5mvAmnNaosZ3gsonSEFgiZMewkimJYyYfHjHv2kpw51Hekwr aa8dvJ
dunAhzeTTCdghxhT2p2hsKXARB5m4D0vJv2aEcxnR1xxvDA/2uggxfXJi185CpAk
qx1JzegPv+xRvp/jTp1w1GpmuemJILGs95iF0v8wpUFM3xDR3o8Gcu018eokEEA
1pwngiRuQcjJh464Z8rbr810+FJP0AheJ7XufwIDAQABAoIBABStQHN8Em7Jot05
HKwqbb4rgonj36seEsZjs51ff9KibJ0rFqsUyYQBjHqp6iLvg5om1+GQREg99M4f
ka2xSBC56uoKxvMwTh4e/6dwrqHoUiIFKtrEgE84EYxIPettniZwJ1TipjoarOp
XTf5JtJmLGOYT71u9kVbSUIsmptxn8xNu1po511zY/Soy3p38gTKwNj1n9CnJXo
q9Ltnf1Gvq7JfRhjHF4AYKJszMNE4ZI4Wer4B72wxifpINr011k0ezrKn5uub+Ug
8nXONonXAlotv7MCim+u4cJv8ww3ytb7Mw5isAS9zes9e5ticiLLh5yFFjYvKaI6
e2HgpEEcgYEA7XY94+z2xy48z5ogQERghCwFv7wWP6kuobJgKITcygP0N5jJqkSuo
pprTpr4gpvH8v78krPASSdxrmm3UyvmrK5z89T0SQMns1s6HX+vfVsvHxmkW3wa6
BChA2+YsHPTpfEAYK/ruxh/3rRb1FoptFpiHpmYEWNowyXT2Jg2HPCCgYEA2L+D
t6hVfnsCODcr1KE2VGEMLGD6112eUBp3/6+MrAggdVqaaBgxuv57swNS7Ys4Fv7V
Eiot/CwDCB4uIIK4mbenw39uu2OZAGceNxmOmdosg97Vxs7GR76tyC9ireiu0HX2
Yspb5L8cb1PevTP058GHVjqhkmSr zqx/URx9ALkCgYEAyhzC6Yka0bnp6svCMrUG
MTON209S506h1dBQmWFC30wsixzJ26vaJz+oLMwVYd4cgricv8i4QDXL++s5i3r
r3w1EwhczmLcI5e0Qf/c3Fqt8d2pgtAp7EXzMH9itJiux85P5PkSdm/FmuPTI1zn
uym1yePXNKNSNqsutTokolUCgyAsRWHX/ihfjB/FykDRNORT87Hir5x/FvAdK35
8ZdgBIO1tk3ZGSF/M798CFeeQw1hdQd8QE25HbvngKJvTYP7EciDNFIWFYecPHO
pqiY1PXU4qcovVo7g981gdn2KNbYCAw0pawdtp4vK7AIn6hx6w09sa4a/utVDw1
CxavMQKBgFhjvBHD9CKY41kMtyHvNpaxmJatw1EBMyvKfWatz+e4C+ojzylU134e
TPkk8ivxeZ00c8X241dIBZKbwCLnV3TprvA2Uemu15LjyU0H4AEInzan1H4S2G+Rz
gWwEFZmTlg0R7f7H9uBPponjnjzhsAMkBAVgwpJvY6PyoPP0tg1r
-----END RSA PRIVATE KEY-----
-----BEGIN CERTIFICATE-----
MIIDAZCCA1OgAwIBAgIJAM1b9H5kqNSpMA0GCsGqSIb3DQEBCwUAMFkxZAJBgNV
BAYTA1VMTMqswCQYDVQGEwJPSDEMMaOGA1UECHMD1RJMq8wDQYDVQQDEwZOVkQ
Q0EXHjACBgkqhkiG9w0BCQEQwD3NhbGZvZG50awdVLMnVbTAeFw0xODEyMDQy
MzhaFw0yMTA5MjMyMDA1MzhaMHEXc2AJBgNVBAYTA1VMTMqswCQYDVQGEwJPSDEP
MA0GA1UEBXMGMXvYy3JhMQwwCgYDVQQKEwNOVEkxZAJBgNVBAMTDE5Mi4xNjgu
My4xNDQxHjAcBgkqhkiG9w0BCQEQwD3NhbGZvZG50awdVLMnVbTCCAS1WdQyKozI
hvcNAQEBBQADgGEPADCCAQoQggEBAMkNAZ5UZK96+MjQ1YtI2Kxvtvml6r+1q6LT
MhnyEwmwzC605dc1wG/7hxf91j3Pp+v+8A2t4Gsk+oiZzIv3Vx/F9eokR4n1kflH
QIkBpw+8/gf3SImjOb6gze80ZrWjPzWjrGd4LDp0hBYImTHSjIpiWmsnx479pKV
udR3pFq2mvHVSxbpwiC3k03A4IcYU9gdoBcsQEZeUa9L479mHMZ0YscbwP9r0
IMX1yYpfEgqQJKsYic3qj7/sub6f406SNCJRj5rnp1SCxrPeyhdL/FqvBTN8Q0d6
PBgrtJfHqjBBAjAvjYIKbkhi44eouGfK26/JdPhst9AIRce17n8CAwEAAMeMwW
CQYDVROTBAAIwADAPBgNVHREEDAGHwTAAQAOQMA0GCsGqSIb3DQEBCwUAA4IBAQ
dCNA7H/4deYR70j13yOmN9ajGRU5XbzETNA1Cr+3w+2YuaJ4CA0do/e9TLwHTC1PH
E1HkrKfyJag5JEE32PT/Pn+gb++/ZU94jw7qatqr cwiboy7ytJczgEKYOEPjVJ
f51savbgwmQGAOLURr2NLLU9vCY1TpeeTGyC/ve5k3rjOYFacQL5rKa9D7Vgn6r
IwTU13uwvDXP7QzvkGjKueJkw1g2D1MS3bw2ejaO0c9HA18RCROxm5527marqELZJ
GLbf3587pCZMQiU21YU9Dj/70R5N1xdyKQG4kNFoxMHkmuAafqIFp+d8d+3xtVSw
h94zxQI77VarHXLswk3e

```

On the VEEMUX Web Interface menu Under “Administration” select “Network”. In X509 certificates, select “Choose File”, select the combined server certificate /key file, click “Upload Server certificate and key”.

### 3. Uploading External CA Certificate to VEEMUX Device:

```

-----BEGIN CERTIFICATE-----
MIIDtjCCAp4CCQdy25JKAce+ddANBgkqhkiG9w0BAQ0FADCnDELMAkGA1UEBHMCM
VVMxZAJBgNVBAGTAK9IMq8wDQYDVQGEwD3NhbGZvZG50awdVLMnVbTAeFw0xODE
yMDQyMzhaFw0yMTA5MjMyMDA1MzhaMHEXc2AJBgNVBAYTA1VMTMqswCQYDVQGEw
JPSDEPMA0GA1UEBXMGMXvYy3JhMQwwCgYDVQQKEwNOVEkxZAJBgNVBAMTDE5Mi4x
NjguMy4xNDQxHjAcBgkqhkiG9w0BCQEQwD3NhbGZvZG50awdVLMnVbTCCAS1WdQ
yKozIhvcNAQEBBQADgGEPADCCAQoQggEBAMkNAZ5UZK96+MjQ1YtI2Kxvtvml6r+
1q6LTMhnyEwmwzC605dc1wG/7hxf91j3Pp+v+8A2t4Gsk+oiZzIv3Vx/F9eokR4
n1kflHQIkBpw+8/gf3SImjOb6gze80ZrWjPzWjrGd4LDp0hBYImTHSjIpiWmsnx
479pKVudR3pFq2mvHVSxbpwiC3k03A4IcYU9gdoBcsQEZeUa9L479mHMZ0Yscbw
P9r0IMX1yYpfEgqQJKsYic3qj7/sub6f406SNCJRj5rnp1SCxrPeyhdL/FqvBTN
8Q0d6PBgrtJfHqjBBAjAvjYIKbkhi44eouGfK26/JdPhst9AIRce17n8CAwEAAM
eMwWCQYDVROTBAAIwADAPBgNVHREEDAGHwTAAQAOQMA0GCsGqSIb3DQEBCwUAA
4IBAQdCNA7H/4deYR70j13yOmN9ajGRU5XbzETNA1Cr+3w+2YuaJ4CA0do/e9TL
wHTC1PHE1HkrKfyJag5JEE32PT/Pn+gb++/ZU94jw7qatqr cwiboy7ytJczgEK
YOEPjVJf51savbgwmQGAOLURr2NLLU9vCY1TpeeTGyC/ve5k3rjOYFacQL5rKa9
D7Vgn6rIwTU13uwvDXP7QzvkGjKueJkw1g2D1MS3bw2ejaO0c9HA18RCROxm552
7marqELZJGLbf3587pCZMQiU21YU9Dj/70R5N1xdyKQG4kNFoxMHkmuAafqIFp+d
8d+3xtVSw h94zxQI77VarHXLswk3e
-----END CERTIFICATE-----

```

Get the certificate of your CA in a \*.cer or \*.pem format which should be as shown above. Optionally this file may include an intermediate certificate, which would be different from the above root Certificate, in the same file. On the VEEMUX Web Interface menu Under “Administration” select “Network”. In X509 certificates, click “Choose File”, select this CA certificate file, and click “Upload CA certificate”.

## GENERAL TECHNICAL SPECIFICATIONS

Video	
Video Bandwidth	18 GB/s
Max. Resolution supported	3840x2160 (UHD), and 4096x2160 (4K) @ 60Hz / RGB/YCBCR 4:4:4.
HDMI Compatibility	HDMI 1.4 and 2.0
HDCP Support	v1.4 and v2.2
Color Depth	Up to 12 bits per color
Pixel Encoding	4:4:4, 4:2:2, 4:2:0
Control	
Serial	RS232, RJ45 female connector
Ethernet	RJ45 female connector
Infrared	IR Receiver (works with remote control transmitter)
Power	IEC connector for 100-240VAC power connection
General	
Operating temperature	32 to 104°F (0 to 40°C)
Storage temperature	-20 to 140°F (-30 to 60°C)
Operating and Storage Relative Humidity	5 to 90% non-condensing RH
Dimensions (WxDxH)	SM-16X16-HD4K: <ul style="list-style-type: none"> <li>○ Without cable management tray: 19x14.56x1.75 in (483x370x44 mm).</li> <li>○ With cable management tray: 19x18.36x1.75 in (483x466x44 mm).</li> </ul> SM-32X32-HD4K: <ul style="list-style-type: none"> <li>○ Without cable management tray: 19x18.57x3.5 in (483x472x88 mm).</li> <li>○ With cable management tray: 19x22.48x3.5 in (483x571x88 mm).</li> </ul>

### Switching Latency

Switching latency is the delay time from the moment a switching command is issued to the moment that the new picture is stably displayed on the monitor. The length of this delay depends on many factors, including but not limited to:

- How much difference there is between the two channels to be switched to or from. Resolution, frequency, color depth, color mode etc.
- Whether or not HDCP encryption is involved
- The monitor's characteristic response time

For example, the switching latency using a Sony XBR-55X850D TV was recorded as follows:

- When switching from a 1080p channel to another 1080p channel, it takes about 3 to 4 seconds to show the new channel on the monitor
- When switching from a 1080p channel to a 4k channel, it takes about 5 to 6 seconds to show the new channel.

## INDEX

Backup.....	25	reboot.....	39
baud rate.....	11	Restore .....	25
control options .....	8	RS232 pinout.....	11
DDC.....	10, 34, 36	Scanning Sequences.....	31
Device Discovery Tool .....	41	SerTest .....	14
firmware.....	37	standby mode .....	38
front panel LCD.....	8	Telnet Interface.....	16
IP address.....	22, 27	Telnet-Port 2005.....	18
IRT-UNV .....	42	user management.....	33
Java Runtime Environment.....	41	username and password.....	22
LAN.....	22	Video Switch.....	24
materials supplied.....	2	web browsers.....	1
Matrix Switcher's Control Program .....	13	X509 certificate .....	27, 48
password .....	22		

## WARRANTY INFORMATION

The warranty period on this product (parts and labor) is two (2) years from the date of purchase. Please contact Network Technologies Inc at **(800) 742-8324** (800-RGB-TECH) or **(330) 562-7070** or visit our website at <http://www.networktechinc.com> for information regarding repairs and/or returns. A return authorization number is required for all repairs/returns.

MAN319 Rev.1/3/24